


EVERGREEN WALLS

Installation Guide



evergreen[®]
WALLS

Let's have some
fun together.

Showroom by appointment
48 Winbourne Rd,
Brookvale NSW 2100

info@evergreenwalls.com.au
evergreenwalls.com.au
(02) 8197 3002

Installation Guide

The simple way to a beautiful Green Wall

Congratulations on selecting your new artificial vertical garden from Evergreen Walls. You are just a few steps away from having beautiful greenery in your home or business.

Welcome to our easy installation guide. The best part about your artificial green wall is no structural work is needed before installation, since the panels are very light.

To make installation quicker and easier, we've put together a simple step-by-step guide to help you out. The best part is no special fixtures are required and you'll only need a few things found at your local hardware store.

The installation method will be slightly different depending on the site surface material. Please ensure you use the correct method to achieve the best outcome for long lasting green walls. Please note that you will require a tape measure, spirit level, pencil, sharp scissors, drill, raw plugs, screws, and/or cable ties for installation.



Surface Types

Be sure to note the different surfaces the panels can attach to and what is recommended for each surface:

Gyprock/Plasterboard

Our preference is to screw directly into the wall using a 20mm screw with a good thread. There are pre-made holes on the back of the panels for you to use.

Timber

Simple timber screws only. Try using a screw with a large head for more coverage.

Stone wall

Nylon nail plugs. Pre-drill a hole, place the panel on the wall and hammer the plug. Alternatively pre drill a hole, add a plastic plug and screw.

Concrete

Nylon nail plugs. If you are unable to drill the wall, try cladding the wall with plywood and use timber screws.

Wire fence

Use black cable ties to hold in place

Colorbond Fence

Screw directly using metal screws. If you don't want exposed screws on the other side, you can pre-drill a few holes in the fence and use black cable ties to hold it all in place. If this also isn't an option we recommend making a timber frame for your panels to be mounted on to.

Installation Steps

Evergreen Urban

Did you know we offer Installation Services?

If you're not confident installing or your wall is tricky to access etc, get in touch and we can give you a quote on installing your green wall.

What you will need



Tools

- a step ladder
- a cordless drill
- a spirit level (optional)



People: 1-2



Installation Time: Approx 5mins per panel



Pre-installation advice: We recommend painting your wall black for the best finish! This isn't compulsory, but it will improve your finish for your indoor wall garden.



Backing: Backing composition consists of a LDPE green flexible backing grid which can be cut to size with sharp scissors.



Step 1

Unpack, measure and mark

Use a spirit level to mark guide lines across the top of your wall. These will be your fixing points. Start from the top corner and work your way across. Unpack and lay your green wall panels out in front of your wall.



STEP 2

Secure the first green wall panel

Fix your first panel in place along the marked guide line using the fixing holes on the back of the panel. **Make sure the plants on the panels are facing upward.** Use three screws for the top of the panel to ensure it is fixed completely flat to the wall.



STEP 3

Secure the second green wall panel

Put your next panel in place and screw the top using your guideline to keep level. Lock the two panels together using the clips on the sides. Repeat this process until the top row is complete. Once the top row is locked and fixed in place move down to the next row.



STEP 5

Position and clip the next rows

Place your next panel below the first panel on the top row. Clip the edges of both panels together to lock in place. Repeat until all panels are on the wall.



STEP 6

Secure, screw, trim

Once all panels are clipped in place, screw the top and bottom of each panels to the wall to secure and fix flat against the wall. Use garden snippers to trim any excess overhang at the bottom or sides.