## DETECTOR + PUMP QUICK START GUIDE



1. UNPACK PUMP. CONNECT & SCREW STAINLESS PROBE on INTAKE PORT & TURN ON.



2. UNPACK DETECTOR & TURN-ON. FOLLOW INSTRUCTIONS.







MULTIGAS Professional



MULTIGAS Basic

Copyright © 2019, FORENSICS LLC, all rights reserved. FORENSICS, FORENSICS DETECTORS are registered trademarks of FORENSICS LLC. All other trademarks, trade names, service marks and logos referenced herein belong to their respective companies.

## Support & Sales

WEB: www.forensicsdetectors.com Email: forensicsdetectors@gmail.com











3. CONNECT TUBE TO PUMP OUTPUT PORT AND ONTO DETECTOR CALIBRATION CAP. CONNECT CAP TO DETECTOR.



\* Fore multi-gas detectors, calibration caps require screw to mount the cap, comes within detector box.



\* For Single Gas Detector the cap clips on, no screwing required.

4. BEGIN Probing & Sampling.