

## INSTALLATION GUIDE:

### VW MK7MK7.5 GOLF FRONT TRIANGLE WINDOW FILLER (STREET EDITION)

#### HAVE THE FOLLOWING READY FOR USE

- Micro Fiber Cloths
- Glass Cleaner
- Alcohol Prep Pad (provided in kit)

aerofabb, LLC is not responsible for damage to you or your vehicle while following this Install Guide and/or installing aerofabb products. Please read this install guide in its entirety prior to installing this product.

#### 1. Preparation:

Using a clean **Micro Fiber Cloth** and **Glass Cleaner** of choice, thoroughly clean the front triangle windows and moldings to remove any road grime or debris.

2. Using the provided **Alcohol Prep Pad**, wipe the the front triangle windows and buff with a dry with clean **Microfiber Cloth**.

#### 3. Dry Fit:

Starting on either the passenger or driver's side, fully open your door and dry fit your Window Fillers in place (without removing tape backing). This will give you a good feel on how to properly fit the part into place once the backing is removed. The Window Filler should fit snugly in place with all 3 side making contact with the factory moldings.

#### NOTES:

1. Make sure entire work area around window is clean/free of debris
2. Not all factory moldings are equal. Some small gaps may be present after install. Dry fitting will allow for you to inspect and make necessary alignment changes during install to minimize or close any unwanted gaps.

#### 4. Install:

Starting on either the passenger or driver's side, fully open your door. Ensure window is clear from any oils or debris after dry fit. Peel both strips of backing from the double sided tape. Hold Window Filler at roughly 45° off of the glass while keeping the nose of part pointed inward towards glass. It is important to hover the part away from glass as not to let any tape come in contact with the glass until the part is fit in the correct position.

While hovering the part at roughly 45°, tuck the nose of part forward into position and pivot the rear into place. Slowly level the part flat against glass while keeping an eye on its position around all 3 corners. Once in position, apply firm pressure against adhesive sections and hold for 30 seconds.

Repeat process on opposite side to complete this installation.

At room temperature, approximately 50% of the ultimate strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours.  
-3M Company

