

INSTALLATION QUICK GUIDE

Here is a quick and easy guide to activate your Magic Touch monitor:

1. download the free Displaylink display driver from displaylink.com or support page of mimomonitors.com
2. Plug it into your Windows 7 computer
3. via your control panel, access “tablet controls” and click on “setup”
4. press ENTER to advance setup screen from main monitor to Mimo
5. touch the Mimo screen until it registers as a touch screen

Your Magic Touch is now activated and ready for use.

If desired, you can calibrate your touch screen further via the tablet control calibration procedure. This can be accessed also from the tablet control panel - simply click on the “Display” tab and select the Mimo Monitor from the drop down list, then select “calibrate.”