Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Extra Large Wave-Shaped Banner Stands

- 1. Connect side upright sections together. Shortest upright section should go on top. Repeat for opposite side (fig. A).
- 2. Connect center upright sections together. (fig. B).
- 3. Connect side upright with bottom corner bracket. Repeat for opposite side (fig. C).
- 4. Connect side upright with top corner bracket. Repeat for opposite side (fig. D).
- 5. Connect bottom crossbars together (fig. E).
- 6. Connect top crossbars together (fig. F).
- Slide graphic over frame like a pillowcase and zipper at bottom to complete assembly (not shown).

NOTE: Model shown below may differ from your model. Although the quantity of uprights or crossbars may differ, assembly instructions remain the same.

