Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Hilltop Banner Stands





• Form the base in T position and fix it by turning the plastic connector.





•Open the top clamp profile and place in the poster.



•Open the clamp connected to the foot and place in the other end of poster.



•Complete the assembly of 3 part pipe.



• Place the assembled pipe into the base hole.



• Placing the back connector, hang the banner to the pipe



•Optional with extra cost.



