Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Wall Mounting - Outdoor Enclosed Menu Cases

Step 1

Drill holes in each of the four corners of the cork board (make sure drain holes are on the bottom of the unit when drilling into wall).


Step 2

Drill screws into the wall (use washers to protect the cork board from the screw pressure).

Step 3

Outdoor rated clear sealant can then be used to close up any holes to protect the display.

Screws & Washers





Simple hand tools required: Level, Drill, Screwdriver