Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Outdoor Poster Display Frame - Side Locking Silver Cabinet with Key Set



•Open the cover door.



• Take out the metal stays from the slots inside the cover. Fix the cover in open position by leaning the ends of the metal bars to the plastic holder in the bottom and upper profiles of the frame.




• Fix the frame to the wall through the holes in the canal.



• Place in the poster via the plastic pegs.







7

