


Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Poster Display Rack Assembly 30 Swing Panels (S0060)



STEP 1. Insert the four leveler feet into the two panels.

STEP 2. Screw the two front bars to the two side panels, forming the front of the unit. Use four 2" screws.

STEP 3. Install the back panel. Use four 1" screws.

STEP 4. You have received two sets of grid for poster storage within the base unit. Determine which you want to use; the vertical or horizontal system. Each set has three grid panels; place the panels in slots provided on the inside of the base before installing top.

STEP 5. Install the top frame. The holes face toward the front of the unit. Use four 2" screws. The holes in the bottom cross piece of the top frame for the poster swing frames should be closest to the forward edge. (This allows swing frames to tilt back slightly at the top)

STEP 6. Screw the two wing stops in the bottom section of the top frame. The wing stops should point toward the outside edge of the display. Use two 2" screws.

STEP 7. Install the top panel. Laying horizontally, covering the grid. Face the letters toward the front of the unit.

STEP 8. Move the unit to its permanent location before loading the wings; Be sure to apply Location Sticker Labels above the grid.