Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126 E-MAIL: customerservice@accessdisplaygroup.com

Floorstand

SwingSnaps Floor Sign Holder

INSTRUCTIONS



Step 1

Stand frame on its side on top of shipping carton. Position legs against frame, making sure to line up holes on base with holes on the springs.

Step 2

Screw the legs into the frame

Step 3 (To Place Graphic In)

Lift up side rails and slide clear overlay out.

Step 4

Slide graphic and overlay in and flip close rails.