

Access Display Group, Inc.

TEL: 800-289-1539 FAX: 877-842-5126

E-MAIL: customerservice@accessdisplaygroup.com

Instruction Sheet

Floor Stand Poster SwingStand Sign Holders



STEP 1.

Position frame over base, so the screw in the frame lines up with the hole in the base.

STEP 2.

Screw frame into base. (Do not spin the frame top), turn it slowly, otherwise the screw and hole may be damaged.

STEP 3.

To insert posters, remover liner from Repositionable Adhesive Tapes that are provided in the corners of the backing board, then simply place poster and remove and change as needed.

If your SwingStand has a Side Plunge Lock, simply align the door with lock fitting and press lock stem with finger to lock.