Model: FMPPC2E-410 SOFT COVER
PART NUMBER 798
1 PCS




OUTDOOR LIVING PERFECTED™

Compatible with OUTLAND Living Fire Table models:

ASSEMBLY INSTRUCTIONS

Place Soft Cover on OUTLAND Fire Table.

The Soft Cover is designed with a tapered fit so should be expected to be fairly tight - BUT, REST ASSURED, IT WILL GO ON.



FMI BRANDS INC.



FIRE TABLE! WARNING! HOT SURFACE!

- Slip the Soft Cover over the top four corners of the fire table.
 Note: Do not try to pull one side down until the cover is first over all top four corners of the fire table, or it will not go on properly.
- 3. Pull each side down separately.

To remove the soft cover you must first pull each side all the way up to the top, separately, BEFORE trying to slip cover over top corners of the fire table.

™ Trademark of FMI Brands Inc.

D.798.000.V1



Model: FMPPC2E-410 SOFT COVER
PART NUMBER 798
1 PCS





This is NOT a toy.

Never use the cover on your Outland Fire Table while the Fire Table is in operation.

After use allow the Fire Table to cool for at least 30 minutes prior to deploying the cover.

MAINTENANCE

Simply use warm soap water to wipe down your cover to keep it clean.

Do not use abrasive cleaners.

The Soft Cover material contains UV blocking inhibitors to minimize colour fading, however, the colour will eventually fade, especially when left continuously in the sun.

The Soft Cover is water resistant, but not completely waterproof. The seams may leak some rain water but this will not harm your OUTLAND Fire Table.

Condensation may form under your Soft Cover and this is completely normal.

www.outlandliving.com

™ Trademark of FMI Brands Inc.

