




Two-Piece Joint Drive Axle Set Assembly Manual



Steering Block (Composite) A-03-VBC-0034 x 2
(not included)



Inner Axle for Two-Piece Joint Drive Axle A-03-VBC-0069 x 2



Wheel Axle for Two-Piece Joint Drive Axle A-03-VBC-0070 x 2



Axle Joint for Two-Piece Joint Drive Axle A-03-VBC-0071 x 2



Axle Inner Joint for Two-Piece Drive A-03-VBC-0079



Axle Lock Spring for Two-Piece Joint Drive Axle A-03-VBC-0072



Two-Piece Joint Inner Ball Bearing C-02-BB-1053-B



5x10 Ball Bearing C-02-BB-1005-B (not included)



M1.7x8 Shaft Pin A-03-VBC-0073



M2x12 Shaft Pin B-02-VBC-0020-12



M3x8 Roundhead Screw C-02-SC-RD308 (not included)




M3x2 Set Screw C-02-SC-SS-0302



Ball Connector B-02-VBC-0045 (not included)

Left Joint Assembly



Right Joint Assembly

