



ISO 9001:2008

PROTECTING PEOPLE AND ASSETS FROM FIRE™

877.800.1222 Toll Free
918.551.5500 Main
918.551.5599 Fax

CORPORATE OFFICES:
4129 S. 72nd E. Ave.
Tulsa, OK 74145 USA

www.GSL-inc.com

SPENTEX COVERALL AND WORK SHIRT SIZING INFORMATION

| SPENTEX COVERALL SIZE CHARTS | | | | | | | | |
|----------------------------------|--------|--------|--------|--------|--------|--------|--------|--------|
| ALPHA SIZE | S | M | L | XL | 2X | 3X | 4X | 5X |
| CHEST | 36-38 | 40-42 | 44-46 | 48-50 | 52-54 | 56-58 | 60-62 | 64-66 |
| RG - Regular Length Inseam | 28 | 28 5/8 | 29 3/8 | 30 | 30 3/4 | 31 3/8 | 32 1/8 | 32 3/4 |
| LN - Long Length Inseam | 30 | 30 5/8 | 31 3/8 | 32 | 32 3/4 | 33 3/8 | 34 1/8 | 34 3/4 |
| RG - Sleeve Length from Shoulder | 26 1/2 | 27 | 27 1/2 | 28 | 28 1/2 | 29 | 29 1/2 | 30 |
| LN - Sleeve Length from Shoulder | 28 | 28 1/2 | 29 | 29 1/2 | 30 | 30 1/2 | 31 | 31 1/2 |

- Take your chest measurement around the fullest part of the chest with arms down; just under the arms and across the shoulder blades.
- Take your chest measurement while wearing the outfit that you would wear when donning the coveralls. If you will wear a sweatshirt beneath your flame resistant coveralls, be sure to measure your chest while wearing it.
- If your waist, mid-section or hip area is larger than your chest, measure at your widest point to ensure a proper fit.
- For inseam measure from crotch to top of foot, along inside of leg. Or see chart below based on height.
- Measure sleeve length from shoulder seam of shirt to wrist

| Spentex Coverall Height Conversion Chart | | |
|--|-------|-------|
| RG - Regular | 5'6" | 5'11" |
| LN - Long's | 5'11" | 6'4" |

| SPENTEX WORK SHIRT SIZE CHARTS | | | | | | | | |
|----------------------------------|--------|--------|--------|--------|--------|--------|--------|--------|
| ALPHA SIZE | S | M | L | XL | 2X | 3X | 4X | 5X |
| CHEST | 36-38 | 40-42 | 44-46 | 48-50 | 52-54 | 56-58 | 60-62 | 64-66 |
| RG - Regular Length | 28 | 28 5/8 | 29 3/8 | 30 | 30 3/4 | 31 3/8 | 32 1/8 | 32 7/8 |
| LN - Long Length | 29 1/2 | 30 1/8 | 30 7/8 | 31 1/2 | 32 1/4 | 32 7/8 | 33 5/8 | 34 1/2 |
| RG - Sleeve Length from Shoulder | 25 1/4 | 25 1/2 | 25 3/4 | 26 | 26 1/4 | 26 1/2 | 27 | 27 1/4 |
| LN - Sleeve Length from Shoulder | 26 3/4 | 27 | 27 1/4 | 27 1/2 | 27 3/4 | 28 1/4 | 28 1/2 | 28 3/4 |

*Body length of shirt is determined from shoulder seam near collar, down the front of shirt to the bottom of hem near the placket.