



1	406022	FRONT ENDBELL	34	2013000	E-RING-
2	406402	BRUSH PLATE ASSEMBLY	35	2010110	KNOB-TILT
3	406081	BRUSH SPRING (2 REQ'D)	36	2031831	HINGE
4	406072	BRUSH ASSEMBLY (2 REQ'D)	37	2011385	SCREW-TENSION KNOB
5	406341	BRUSH PLATE SCREW (2 REQ'D)	38	2032800	TENSION BLOCK
6	401050	THRUST DISK	39	2037300	BUSHING-HINGE (2 REQ'D)
8	406090	BRUSH HOLDER	40	2331303	SCREW-1-1/2"
9	406206	ARMATURE ASSEMBLY	41	2333101	NUT-HEX
10	405300	E-RING	42	2031520	COLLAR-DEPTH
11	406170	THRUST WASHER- STEEL (AS REQ'D)	43	2011365	SCREW-COLLAR KNOB
12	405171	THRUST WASHER- NYLON (AS REQ'D)	44	2162541	CONTROL BOX
13	406480	GASKET	45	2066940	GASKET- CONTROL BOX
14	406255	CENTER SECTION W/MAGNETS	46	2060251	CONTROL BOX COVER
14A	2006607	DECAL (2 REQ'D)	47	2365625	DECAL COVER
15	406460	O-RING	48	2012100	SCREW 5/8" (9 REQ'D)
16	406032	REAR ENDBELL	49	2052900	STRAIN RELIEF
16A	406600	FLANGE BEARING (SERVICE CENTERS ONLY)	50	2360901	HANDLE ASSEMBLY
17	406461	SEAL	51	2010000	BEARING- HANDLE INNER
18	406471	SEAL- CUP	52	2010011	BEARING- HANDLE OUTER
19	401462	O-RING- THRU BOLT (2 REQ'D)	53	2364001	CONTROL BOARD ASSEMBLY
20	406352	THRU BOLT (2 REQ'D)	54	2365105	INSULATING PAD
21	2092600	PIN- DRIVE	55	2301710	WASHER-INSULATED
22	2061121	PROPELLER	57	2060300	RETAINER
23	2051700	LOCKWASHER	58	2332103	SCREW- 3/8" (2 REQ'D)
24	2053100	NUT- PROP	59	2010030	HANDLE BEARING CAP
25	2369050	MOTOR ASSEMBLY	60	2361700	WASHER-STOP
26	2032051	TUBE 30"	61	2362710	SPRING
27	2991800	BRACKET AND HINGE ASSEMBLY (INCLUDES 27A,28-39)	62	2362811	ACTUATOR-POT
*27A	2031910	BRACKET (ORDER 27B)	63	2332830	ADAPTER-DISC
27B	2771907	BRACKET ASSEMBLY (INCLUDES 27A,29-31)	64	2364000	SWITCH-FWD/REV
28	2010511	PIN- HINGE	65	2050600	LEADWIRE (10 DA) CLIPS
29	2011375	SCREW-CLAMP (2 REQ'D)	66	2010700	BATTERY CLIPS (2 REQ'D)
30	2011710	WASHER-CLAMP SCREW (2 REQ'D)	67	2305800	DECAL LEADWIRE (BATTERY)
31	2013010	RETAINING-RING (2 REQ'D)			
32	2033602	T-BAR			
33	2012700	SPRING- T-BAR			

65MX

BATTERY METER

