



5157

- | | | |
|---|--|---|
| 1 403028 BRUSH END HOUSING W/ COIL RT27/S | 27 2053100 NUT-PROP | 57 2990911 HANDLE ASSY-WU-JOINT 5SP |
| 405025 BRUSH END HOUSING RT38/S | 28 2092600 PIN-DRIVE SS | 58 2060000 HANDLE BEARING (2 REQ'D) |
| 2 406408 BRUSH PLATE ASSEMBLY RT27/S | 29 2991983A BRACKET-KOTA STOW-ASSY SW | 59 2771809 U-JOINT ASSEMBLY |
| 3 406084 BRUSH SPRING (2 REQ'D) | 29A 2771909 BRACKET ASSY (INCLUDES 29B-32) | 60 2302742 SPRING-DETENT (OFF) SS |
| 4 406074 BRUSH ASSEMBLY (2 REQ'D) | *29B 2031922A BRACKET-DIE-CAST-SW (ORDER 29A) | 61 2302743 SPRING-DETENT HANDLE-TILT |
| 5 406341 BRUSH PLATE SCREW (2 REQ'D) | 30 2011378 SCREW-CLAMP/NEW KNOB SS (2 REQ'D) | 62 2302745 SPRING-RELEASE BUTTON SS |
| 6 2066649 DECAL MOTOR "RIPTIDE" (2 REQ'D) | 31 2331700 WASHER-CLAMP SCREW 1.5 OD (2 REQ'D) | 63 2303720 RELEASE BUTTON-HANDLE |
| 7 403050 THRUST DISK | 33 2034301 ARM-LINK (LOWER) SW | 64 2060410 HANDLE (TOP HALF) |
| 9 403010 STEEL BALL | 34 2030502 PIN-PIVOT (LOWER ARM) | 65 2060415 HANDLE (LOWER HALF) |
| 10 406090 BRUSH HOLDER | 35 2034201 ARM-LINK (UPPER) SW | 66 2303412 SCREW-6-20 X 5/8 SELF TAP (11 REQ'D) |
| 11 403208 ARMATURE ASSEMBLY RT27/S | 36 2030501 PIN-PIVOT (UPPER ARM) | 67 2060005 BEARING-HANDLE PIVOT (2 REQ'D) |
| 405205 ARMATURE ASSEMBLY RT38/S | 37 2283011 E-RING 3/8 DIA. SHAFT (4 REQ'D) | 68 2010701 BATTERY CLIPS (2 REQ'D) |
| 12 405300 E-RING | 38 2030981 HANDLE-TILT (SW) | |
| 13 408170 THRUST WASHER- STEEL (AS REQ'D) | 39 2031701 WASHER-SPRING SEAT SS | |
| 14 405171 THRUST WASHER- NYLON (AS REQ'D) | 40 2012701 SPRING-LOCKBAR SS | |
| 15 403460 O-RING | 41 2033605 LOCKBAR (KOTA STOW) | |
| 16 403258 CENTER SECTION WMAGNETS RT27/S | 42 2033011 E-RING 5/32 SS | |
| 405260 CENTER SECTION WMAGNETS RT38/S | 43 2032020 TUBE-GUIDE (KOTA STOW) | |
| 17 406460 O-RING | 44 2030500 PIN-PIVOT (LINK/TUBE) (2 REQ'D) | |
| 18 403032 PLAIN ENDBELL | 45 2037300 BUSHING-HINGE (2 REQ'D) | |
| *18A 406600 FLANGE BEARING (SERVICE ONLY) | 46 2032800 TENSION BLOCK | |
| 19 406461 SEAL | 47 2031520 COLLAR-DEPTH (W/O INSERT) | |
| 20 406471 SEAL- CUP | 48 2011368 SCREW-COLLAR/NEW KNOB SS (2 REQ'D) | |
| 21 401462 O-RING —THRU BOLT (2 REQ'D) | 49 2050602 LEADWIRE W/CLIPS SW | |
| 22 403354 THRU BOLT RT27/S (2 REQ'D) | 50 2062551 CONTROL BOX | |
| 405352 THRU BOLT RT38/S (2 REQ'D) | 51 2060263 COVER-CONTROL BOX | |
| 23 2039075 MOTOR ASSEMBLY RT27/S | 52 2035682 DECAL-COVER RT27/S | |
| 2069046 MOTOR ASSEMBLY RT38/S | 52 2085682 DECAL-COVER RT38/S | |
| 24 2032052 TUBE (COMPOSITE) 36" OPTIONAL | 53 2064023 SWITCH-FWD/REV COMBO-5 SP | |
| 25 2061125 PROP (WEEDLESS WEDGE) | 55 2332102 SCREW-10-24 X 1-3/4 SS | |
| 26 2051700 LOCKWASHER-PROP | 56 2333101 NUT-HEX | |

RT27/S RT36/S

This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.

