



For any parts ordered from Card, MasterCard or VIS
 ordering parts. Please use the correct part numbers from the parts list. Payment
 MINN KOTA parts department, may be by cash, personal check, Discover
 order, call 1-800-227-8433 or FAX 1-800-527-4484.

Ne pas oublier de fournir les numéros de Modèle et de Série
 of votre Modèle lorsque vous placez une commande.
 Employez le numéro de pièce exact se trouvant sur
 la list des pièces de remplacement.

para identificar o Centro de Serviço Autorizado MINN KOTA.
 Não deixe de incluir o número do MODELO e o número de
 SÉRIE do seu motor ao pedir peças. Sem
 números corretos das peças da lista de peças.

1	409022	BRUSH END HOUSING	39	2012701	SPRING-LOCKBAR SS
2	406403	BRUSH PLATE ASSEMBLY	40	2033605	LOCKBAR (KOTA STOW)
3	406082	BRUSH SPRING (2 REQ'D)	41	2033011	E-RING 5/32 SS
4	406071	BRUSH ASSEMBLY (2 REQ'D)	42	2032020	TUBE-GUIDE (KOTA STOW)
5	406342	BRUSH PLATE SCREW (2 REQ'D)	43	2030500	PIN-PIVOT (LINK/TUBE) (2 REQ'D)
6	406010	BALL BEARING	44	2037300	BUSHING-HINGE (2 REQ'D)
7	406208	ARMATURE ASSEMBLY	45	2032800	TENSION BLOCK
8	405300	E-RING	46	2031520	COLLAR-DEPTH (W/O INSERT)
9	406170	THRUST WASHER- STEEL (AS REQ'D)	47	2011366	SCREW-COLLAR/NEW KNOB (2 REQ'D)
10	405171	THRUST WASHER- NYLON (AS REQ'D)	48	2332900	STRAIN RELIEF
11	406490	GASKET	49	2330600	LEADWIRE (10 GA) RINGS
12	409254	CENTER SECTION W/MAGNETS	50	2062584	CONTROL BOX-DIE CAST ZINC
13	2066649	DECAL MOTOR (2 REQ'D)	51	2081511	COLLAR-CTRL BOX
14	406470	O-RING	52	2305622	DECAL-COVER
15	409032	PLAIN END HOUSING	53	2300227	COVER-CONTROL BOX
16	406600	FLANGE BEARING (SERVICE ONLY)	54	2990815	HANDLE ASSY W/O U-JOINT
17	406481	SEAL	55	2060000	HANDLE BEARING (2 REQ'D)
18	408471	SEAL- CUP	56	2302742	SPRING-DETENT (OFF) SS
19	405462	O-RING —THRU BOLT (2 REQ'D)	57	2302743	SPRING-DETENT HANDLE-TILT
20	406353	THRU BOLT (2 REQ'D)	58	2302745	SPRING-RELEASE BUTTON SS
21	2099065	MOTOR ASSEMBLY	59	2303720	RELEASE BUTTON-HANDLE
22	2091150	PROP (WEEDLESS WEDGE)	60	2060411	HANDLE (TOP HALF)
23	2051700	LOCKWASHER-PROP	61	2060415	HANDLE (LOWER HALF)
24	2053100	NUT-PROP	62	2303412	SCREW-8-20 X 5/8 SELF TAP (11 REQ'D)
25	2092600	PIN-DRIVE SS	63	2060005	BEARING-HANDLE PIVOT (2 REQ'D)
26	2032053	TUBE (COMPOSITE) 42"	64	2302600	PIN-ACTUATOR
29	2991963	BRACKET-KOTA STOW-ASSEMBLY	65	2302850	ACTUATOR-CAM
29A	2771909	BRACKET ASSY (INCLUDES 29B—31)	66	2302851	ACTUATOR-FWD/REV
*29B	2031922	BRACKET-DIE CAST (ORDER 29A)	67	2302740	SPRING-ACTUATOR
30	2011376	SCREW-CLAMP KNOB (2 REQ'D)	68	2302741	SPRING-CAM
31	2331700	WASHER-CLAMP SCREW 1.5 OD (2 REQ'D)	69	2334007	CONTROL BOARD ASSEMBLY
32	2034301	ARM-LINK (LOWER)	70	2372100	SCREW-8-18 X 5/8 SS (4 REQ'D)
33	2030502	PIN-PIVOT (LOWER ARM)	71	2301310	SCREW-8-18 X 1/2 SS (2 REQ'D)
34	2034201	ARM-LINK (UPPER)	72	2301710	WASHER-INSULATED-TRANSF.BAR (2 REQ'D)
35	2030501	ARM-LINK (UPPER ARM)	73	2385105	INSULATING PAD
36	2263011	PIN-PIVOT (UPPER ARM)	74	2090700	RING TERMINALS (2 REQ'D)
37	2030981	E-RING 3/8 DIA. SHAFT (4 REQ'D)	75	2060310	FUSED GROUND WIRE
38	2031701	HANDLE-TILT	76	2305810	TAG- AIR SWITCH LEADS
		WASHER-SPRING SEAT SS			

* This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.

133

RT42/S

RT42/S

