


50T
32Lbs. Thrust
12 Volt
36" Shaft



In the U.S.A., replacement parts may be ordered directly from MINN KOTA Parts Dept., JWA MARINE, 706 Howard Ave, Markato, Minnesota 56001. In Canada, parts may be ordered from any of the Canadian Authorized Service Centers shown on the enclosed list. Be sure to provide the MODEL and SERIAL numbers of your motor when ordering parts. Please use the correct part numbers from the parts list. Payment for any parts ordered from the MINN KOTA parts department, may be by cash, personal check, Discover Card MasterCard or VISA. To order, call 1-800-227-6433 or FAX 1-800-527-4464.

Fuera de los Estados Unidos, consultar la lista anexa para ubicar el Centro de Servicio autorizado MINN KOTA. No dejar de incluir el número del MODELO y el número de SERIE del motor para el cual se solicitan las piezas. Usar siempre los números de pieza correctos indicados en la lista de piezas.

Hors de États-Unis, voir la liste ci-jointe pour le Centre de Service Agréé MINN KOTA le plus proche. Lors d'une commande, ne pas oublier de fournir le numéro de modèle et le numéro de série du moteur. Toujours mentionner le numéro de pièce exact figurant sur la liste des pièces de rechange.

Fora da América do Norte, consulte a lista anexa para identificar o Centro de Serviço Autorizado MINN KOTA. Não deixe de incluir o número do MODELO e o número de SÉRIE do seu motor ao pedir peças. Sempre use os números corretos das peças da lista de peças.

1	406027	FRONT ENDBELL W/SP COIL	30	2011710	WASHER-CLAMP SCREW (2 REQ'D)
2	403460	O-RING	31	2033602	T-BAR
3	406405	BRUSH PLATE ASSEMBLY	32	2012700	SPRING-T-BAR
4	406081	BRUSH SPRING (2 REQ'D)	33	2013000	E-RING
5	406072	BRUSH ASSEMBLY (2 REQ'D)	34	2010111	KNOB-TILT
6	406341	BRUSH PLATE SCREW (2 REQ'D)	35	2031831	HINGE
7	403050	THRUST DISC	36	2037300	BUSHING-HINGE (2 REQ'D)
8	403010	BALL	37	2011385	SCREW-TENSION W/NEW KNOB
9	406090	BRUSH HOLDER	38	2062800	TENSION BLOCK-"SNAP IN"
10	405205	ARMATURE ASSEMBLY	39	2061520	COLLAR-DEPTH ENDURA
11	405300	E-RING	40	2011365	SCREW-COLLAR W/NEW KNOB
12	406170	THRUST WASHER- STEEL (AS REQ'D)	41	2062551	CONTROL BOX
13	405171	THRUST WASHER- NYLON (AS REQ'D)	42	2060281	CONTROL BOX COVER- (BLK)
14	405259	CENTER SECTION W/MAGNETS	43	2065609	DECAL COVER-50TA
14A	2006603	DECAL- LOWER UNIT WHITE	44	2064023	SWITCH-FWD/REV COMBO-5 SP
15	406460	O-RING	45	2033400	SCREW-10-24 X 1-3/4
16	406035	PLAIN END HOUSING	46	2013110	NUT-HEX (ZINC/CAD PLATE)
16A	406600	FLANGE BEARING (SERVICE ONLY)	47	2990912	HANDLE ASSEMBLY W/U-JOINT 5SP
17	406461	SEAL	48	2060000	HANDLE BEARING (2 REQ'D)
18	406471	SEAL W/CUP	49	2302742	SPRING-DETENT (OFF) (SS)
19	401462	O-RING —THRU BOLT(2 REQ'D)	50	2302743	SPRING-DETENT (HANDLE)
20	405352	THRU BOLT (2 REQ'D)	51	2302745	SPRING-RELEASE BUTTON (SS)
21	2069041	MOTOR ASSEMBLY	52	2303720	RELEASE BUTTON-HANDLE
22	2032052	TUBE (COMPOSITE) 36"	53	2060408	HANDLE (TOP HALF)
23	2061125	PROP (WEEDLESS WEDGE)	54	2060415	HANDLE (LOWER HALF)
24	2051700	LOCKWASHER-PROP (MEDIUM)	55	2303412	SCREW-6-20 X 5/8 SELF TAP (11 REQ'D)
25	2053100	NUT-PROP (MEDIUM)	56	2060005	BEARING-HANDLE PIVOT (2 REQ'D)
26	2092600	PIN-DRIVE (SS)	57	2050600	LEADWIRE (10 GA W/CLIPS)
27	2991800	BRACKET & HINGE ASSEMBLY (INCLUDES 27A, 28-39)	58	2010700	BATTERY CLIPS (2 REQ'D)
*27A	2031910	BRACKET (ORDER 27B)		406245	REPLACEMENT SPEED COIL (NOT SHOWN)
27B	2771907	BRACKET ASSEMBLY(INCLUDES 27A, 29-30)			
28	2010511	PIN-HINGE			
29	2061300	SCREW-CLAMP ENDURA(2 REQ'D)			

Turbo Transom Series Wiring Diagrams

50T, 65T, 90T-XI, Camo 44

