

In the U.S.A., replacement parts may be ordered directly from MINN KOTA Parts Dept., P.O. Box 100, Mankato, Minnesota 56001. In Canada, parts may be ordered from any of the authorized Service Centers shown on the enclosed list. Please use the correct part numbers from the parts list. Payment for any parts ordered from the MINN KOTA parts department, may be by cash, personal check, Discover Card, MasterCard or VISA. To order, call 1-800-227-6433 or FAX 1-800-527-4464.

Fuera de los Estados Unidos, consultar la lista anexa para ubicar el Centro de Servicio autorizado MINN KOTA. No olvidar de incluir el número del MODELO y el número de SERIE del motor para el cual se solicitan las piezas. Usar siempre los números de pieza correctos indicados en la lista de piezas.

Hors de États-Unis, voir la liste ci-jointe pour le Centre de Service Agréé MINN KOTA le plus proche. Lors d'une commande, ne pas oublier de fournir le numéro de modèle et le numéro de série du moteur. Toujours mentionner le numéro de pièce exact figurant sur la liste des pièces de rechange.


Fora da America do Norte, consultar a lista anexa para identificar o Centro de Serviço Autorizado MINN KOTA. Não deixe de incluir o número do MODELO e o número de SÉRIE do seu motor ao pedir peças. Sempre use os números corretos das peças da lista de peças.

1	116-025	BALL - STEEL	37	2333001	E-RING- SS
2	2-100-103	ARMATURE ASSEMBLY 24V 4	38	2332700	SPRING- T-BAR
3	788-040	RETAINING RING	39	2033601	T-BAR E-COAT
4	2-200-098	CENTER HOUSING FIELD ASSEMBLY	40	2037300	BUSHING-HINGE [2.EA]
5	2-300-013	BRUSH END HOUSING ASSEMBLY	41	2062800	TENSION BLOCK- "SNAP IN" [2.EA]
6	144-017	BEARING - FLANGE	42	2011386	SCREW-TENSION/NEW KNOB
7	880-025	SEAL [2.EA]	43	2061520	COLLAR-DEPTH
8	2-400-012	PLAIN END HOUSING ASSEMBLY	44	2011366	SCREW-COLLAR/NEW KNOB SS
9	144-021	BEARING - SPHERICAL	45	2332900	STRAIN RELIEF-C.CORD/C.
10	784-025	BEARING RETAINER	46	2330600	LEADWIRE (10 GA-4) RINGS
11	991-040	WASHER - FELT	47	2303001	RING-PIG LOXIT HILL #2
12	303-043	THRUST DISC - METAL	48	2062588	CONTROL BOX,SW, .875 BORE
13	701-009	O-RING [2.EA]	49	2061513	COLLAR-CTRL BOX
14	701-043	O-RING [2.EA]	50	2301310	SCREW-8-18 X 1/2 SS [2.EA]
15	830-027	SCREW - SELF-THREAD 10-32X2 [2.EA]	51	2301710	WASHER-INSUL. (TRANSF.BAR) [2.EA]
16	830-094	THRU BOLT 12-24 x 10.31 [2.EA]	52	2340610	CONNECTOR CABLE- 12"
17	973-025	SPACER - BRUSHPLATE [2.EA]	53	2305810	TAG-AIR SWITCH LEADS
18	990-051	WASHER - STEEL THRUST	54	2344007	CONTROL BOARD ASSEMBLY SW
19	990-052	WASHER - NYLATRON	55	2305400	SHRINK TUBE-3/8 OD [8.EA]
20	975-041	SPRING - TORSION [2.EA]	56	2372100	SCREW-8-18 X 5/8 THD [2.EA]
21	738-004	BRUSH PLATE-4" TERMINAL	57	2263406	SCREW-10-24 X 2 SS PPH
22R	409071	BRUSH / RED WIRES	58	2333101	NUT-10-24 NYLOCK SS UNC 2B
22B	409071	BRUSH / BLACK WIRES	59	2300227	CONTROL BOX CVR SW
23	2317040	MTR ASSEMBLY 24V 4 VARS SW HG	60	2095617	DECAL-COVER (RT74/S)
24	2032053	TUBE (COMPOSITE) 42"	61	2990915	HANDLE ASSEMBLY W/O U-JOINT
25	1378129	PROPELLER- KIT INCL. 25,26,27,28	62	2302742	SPRING-DETENT (OFF) SS
26	2091700	LOCKWASHER-PROP (LARGE)	63	2302743	SPRING-DETENT HANDLE-TILT
27	2093100	NUT-PROP (LARGE)	64	2302745	SPRING-RELEASE BUTTON SS
28	2092600	PIN-DRIVE SS	65	2303720	RELEASE BUTTON-HANDLE
29	2066603	DECAL- LOWER UNIT WHITE	66	2060411	HANDLE (TOP HALF) MAXIMIZER
■	2771961	BRACKET & HINGE ASSEMBLY SW	67	2060415	HANDLE (LOWER HALF)
30	2771905	BRACKET DIE CAST-E-CT/PN INCL. 30,33,34	68	2303412	SCREW-6-20 X 5/8 SELF TAP [11.EA]
31	2330500	PIN-HINGE (BRACKET)	69	2060005	BEARING-HANDLE PIVOT
32	2333100	NUT-SPEED SS [2.EA]	70	2302600	PIN-ACTUATOR
33	2011376	SCREW-CLAMP/NEW KNOB SS [2.EA]	71	2302850	ACTUATOR-CAM
34	2331700	WASHER-CLAMP SCREW 1.5 OD [2.EA]	72	2302851	ACTUATOR-FWD/REV
35	2031855	HINGE-MACH.IN-HOUSE SS	73	2302740	SPRING- (ACTUATOR)
36	2010100	KNOB-TILT	74	2302741	SPRING-CAM ZNC PLTD STEEL
			75	2060310	CONNECT GROUND WIRE-FUSED

RipTide Transom Series Wiring Diagrams

RT65/S

BLACK LEADS B-



RT74/S

BLACK LEADS B-

