

## EQUICIZER RISER STAND INSTRUCTIONS

Tools you may need:

$\frac{3}{4}$ " wrench

$\frac{3}{4}$ " ratchet

1.) Lay out all your pieces.




2.) Assemble the cross brace of the Riser Stand using the bolts that are in place.  
**DO NOT FULLY TIGHTEN ANY OF YOUR BOLTS YET!**



3.) The Equicizer comes set at 14 hands tall. Set your desired height from 14 up to 16 hands. Height settings are marked circled in red in photo. Bolts for adjustment are not fully tightened **DO NOT FULLY TIGHTEN BOLTS YET!**



- 4.) The Riser Stand is now completely assembled with all bolts in place but NOT FULLY TIGHTENED. With at least 2 people, carefully lift the Equicizer on to the Riser Stand. Line up as best you can the threaded ends on the Equicizer's bottom frame to the Riser Stand's foot plates with the holes (see below circled in red).



- 5.) Line up the threaded holes on the Equicizer's frame to the Riser Stand foot plates. Riser Stand bolts are still loose to help line up the Riser Stand to the Equicizer's frame. Line up one plate at a time and place bolt with washer under Riser Stand foot plate and hand turn to get started. DO NOT TIGHTEN until all 4 bolts of Riser Stand foot plates are attached to the Equicizer Frame.



- 6.) Once all 4 bolts are loosely in place tighten all 4 bolts completely.

You can now tighten the rest of the bolts on your Riser Stand and assembly is complete. Please contact us with questions!

**Wooden Horse Corporation 819 Dublin Road, Norwalk Ohio 44857**

**Ph: 419-663-1472 Email: [info@equicizer.com](mailto:info@equicizer.com)**

**Web address: [www.equicizer.com](http://www.equicizer.com) or [www.exercisehorse.com](http://www.exercisehorse.com)**