



POWERCAP INSTALLATION:

* - REFERENCE USER MANUAL FOR POWERCAP REMOVAL AND BATTERY REPLACEMENT

1. AFTER REMOVING POWERCAP AND O-RINGS, WIPE O-RINGS AND POWERCAP WITH A CLEAN, DRY TOWEL, ENSURING NO DIRT OR OTHER CONTAMINANTS.
2. APPLY A LIGHT COATING OF O-RING LUBE TO THE O-RINGS.
NOTE: MAKE SURE GREASE DOES NOT GET INTO ANY ELECTRICAL CONNECTIONS, AS THIS MAY CAUSE DAMAGE TO THE HUB OR POWERCAP.
3. INSTALL QUAD RING ONTO TORQUE TUBE, ENSURING IT IS NOT TWISTED AND PROPERLY SEATED IN GROOVE.
4. SEAT THE RED POWERCAP O-RING INTO THE NON-DRIVE SIDE OF THE HUB.
5. INSTALL THE POWERCAP AND TIGHTEN THREADED NUT HAND TIGHT TO SECURE.



SARIS CYCLING GROUP
 5253 VERONA RD., MADISON WI. 53711
 1-800-783-7257 / 1-608-274-6550
 WWW.SARIS.COM WWW.CYCLEOPS.COM
 WWW.POWERTAP.COM



© SARIS CYCLING GROUP 2014
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE CONFIDENTIAL PROPERTY OF SARIS CYCLING GROUP ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF SARIS CYCLING GROUP IS PROHIBITED.

TITLE:
23137 - TRACK HUB ASSEMBLY