

Digislider Carbon Fibre Jib - April 2014 version



supplied:

1. Digislider Carbon Mini Jib
2. Carbon fibre counter balance arm & aluminium handle
3. 75mm Bowl head attachment with screws & allen key
4. Quick Release Adaptor
5. Padded Carry Bag with shoulder harness
6. 4kg Counter Weights (optional extra)

instructions:

Each knob is a resistance screw, but you can have them all loose apart from the one in the centre at the top, and adjust this according to your needs.

To extend the jib, loosen tube connectors and extend the jib to the desired length. Tighten to secure.


The counterweight arm slides in and secures in the same way. The handle unscrews to add the counterweights needed and then screws back on to secure.

Adjust the counterweight arm (closer or further away) to achieve the correct balance.

Counter-weights



1. Counter Weight arm (2.)



2. Unscrew handle and add counter weights.




3. Screw handle back on to stop weights falling off.



4. Fasten weight lock screw to secure weights.

Fix Jib to tripod



5. Secure Jib base to Tripod head.



6. Attach Quick Release Plate Adaptor with Allen Key provided.



7. Attach camera and tighten adaptor to secure.



8. Loosen, extend Jib & tighten. Attach Counter-weight arm.



9. Adjust Counter-weight arm (closer or further away) to achieve balance.



10. Tighten to secure

Resistance Adjustments



Adjust centre top knobs for added resistance. The rest can be loose.

Bowl Attachment



Attach bowl attachment, if needed, with the two screws.