

# COMPLETE KIT

- INCLUDES:  
 1 FIRING HANDLE  
 4 NET LAUNCHERS  
 20 AIR CARTRIDGES  
 1 CARRYING STRAP  
 2 REPLACEMENT O-RINGS  
 4 SPARE END COVER CAPS  
 All contained in a lockable, aluminum, foam lined carrying case



## Net Options:



- 4 inch standard mesh animal capture nets with grapples - **Red Cover**
- 2 inch mesh net used for small birds or extra strength animal catches - **Blue Cover**
- 4 inch mesh net without grapples used for bird capture - **Yellow Cover**
- 6 inch mesh net used for human and large animal capture - **Black Cover**

Please specify net size when ordering based on the projected target species. Net sizes can be mixed at an additional cost.

Additional cartridges can be purchased by calling us directly. These are not standard size cartridges available through retail outlets.

## RELOADING THE NET GUN

Turn the trigger ring to off, remove the launch cone counterclockwise, reset the trigger as described previously, place another launch head in place, remove the spent cartridge and replace with a fresh cartridge, and you're ready for your second catch.

**WARNING:** Once the net gun has been charged, never attempt to remove the base cap or remove the cartridge. The pressured handle must be discharged first. Always point the gun away from people or objects that cannot be damaged.

To discharge a pressurized handle, turn the firing ring to the OFF position.

Remove the launch cone counterclockwise, facing away from people or breakable objects. With the launch cone removed and the end of the launch handle facing the ground; turn the trigger to the ON position and fire at the ground to release the pressure. Once the pressure has been released, it is safe to remove the back cap and remove the spent cartridge.

Failure to follow these instructions can result in serious harm to the operator as well as damage to property.

THIS KIT IS FOR PROFESSIONALS ONLY AND SHOULD NEVER BE TREATED AS A TOY OR USED BY CHILDREN.



[www.humanecapture.com](http://www.humanecapture.com)

**ADVANCED WEAPONS TECHNOLOGY, Inc.**

48290 Vista Calico, Suite A  
 La Quinta, CA 92253  
 Telephone: (760) 777-7229  
 Fax: (760) 777-9930  
 email: [advancedweapons@msn.com](mailto:advancedweapons@msn.com)



# SUPER TALON ULTRA

The latest generation of the world's best-selling net launcher

**ULTRA** light  
**ULTRA** compact  
**ULTRA** fast

Only 12.5 inches long and a light 2.3 pounds

Perfect for field and urban trapping



**ADVANCED WEAPONS TECHNOLOGY, Inc.**

INSTRUCTION MANUAL FOR THE SUPER TALON ULTRA NET GUN



## How it Works:

When you first receive your Super Talon Ultra remove the firing handle from the case, turn the ON/OFF trigger ring to ON and dry fire the handle (without a cartridge). You'll notice the pressure plate fly open which when pressurized would release the charge, firing the net.

# INSTRUCTIONS:

### Turn the ON/OFF trigger ring to OFF

With your finger, press the pressure plate down until you hear a click and you see it engage in place.

(Please note that this can also be done with the ring in the ON position but for safety we advise to ALWAYS do this in the OFF position.)

**WARNING:** When in active use, or when a cartridge is in place, NEVER look into the front or point the handle towards anything that can be injured or damaged.

Attach a net cone to the firing handle by turning the launcher clockwise. The net launcher is removed counterclockwise. It is important to note this because turning the net head clockwise to remove it will bind the plastics together making the net launcher extremely difficult to remove.

**Do not over tighten.**



# 6.

To fire the net, aim the net at the target species (at least ten feet away) and depress the firing button. The net will launch immediately. There will be a slight report sound of the compressed air being released and the target species will be covered by the net.



### CAUTION:

**NOTE:** To detach net launcher turn the net launcher in the direction of the yellow arrow: (counter-clockwise)

## LOADING THE CARTRIDGE



Remove the back cap.



Insert the cartridge into the handle backward with the small end facing out.



Screw the cap onto the back stopping just below the red O-ring. This is the "safe standby firing position" and the gas has not been released into the handle. You can carry this in the field or in your car in this position indefinitely and the net gun will not be charged but will quickly be ready for use.

**THIS IS THE  
STANDBY FIRING POSITION.**



When ready to fire turn the back cap completely covering the red O-ring. The gas will be released into the handle. You may not hear a sound but the handle will become cool.



Turn the trigger ring to the ON position.

**THIS IS THE  
ACTIVE FIRING  
POSITION.**

