



# **Phone Rebel Cases Manual**

**Models: Rebel Series GEN7/Rebel FLEX 17**

<b>Case Installation Guide</b>	<b>Page 2</b>
<b>Installation Guide</b>	<b>Page 3</b>
<b>Camera Lens Installation Guide</b>	<b>Page 4</b>
<b>Tips/Safety</b>	<b>Page 5</b>

# Installation Guide

## 1. Prepare Your Phone and Case

- Start by cleaning your phone to remove any dust, dirt, or fingerprints. Use a soft, lint-free cloth to gently wipe the screen and the back.
- Clean the inside of the phone case as well, ensuring it's free of debris that could scratch your phone.

## 2. Inspect the Case

- Before installation, inspect the case for any defects such as sharp edges or cracks that could damage your phone or make the case less effective.

## 3. Align Your Phone

- Hold your phone with the screen facing you.
- Align the phone bottom with the case bottom. (Refer to image A)

## 4. Insert Your Phone

- Gently press the phone into the case. Make sure the buttons line up with the button cutouts on the case. (Refer to image A)
- Ease each corner of your phone into the case. You may need to slightly stretch the corners of the case to accommodate the phone.

## 5. Secure the Phone in Place


- Once the phone is placed inside the case, press down on all corners and sides to ensure it's fully seated. You should hear a soft click or feel the phone snugly fit into place, indicating the case is secure. (Refer to image B)

## 6. Final Checks


- After the phone is in the case, go around the edges and press down to ensure there are no loose areas or gaps.
- Check the alignment of the camera and any ports to make sure the case doesn't obstruct them.
- Test the buttons to ensure they have a good tactile response through the case. If they feel stiff or unresponsive, adjust the alignment of the phone within the case or check for any obstructions.

## 7. Adjust as Needed

- If the case has screen protectors or covers, adjust them to avoid air bubbles or misalignment.
- If any parts of the phone are not fitting well, gently remove the phone and repeat the installation process, paying special attention to alignment.




# Buttons/Logo Installation Guide




## Button Installation

1. **Identify the Correct Button Placement:** Match the power, volume, action and camera control buttons on your phone with the corresponding placeholders on the case.
2. **Align the Buttons:** Position the buttons over their respective slots, ensuring they are the right way up.
3. **Press the Buttons into Place:** Gently press each button into its slot until it clicks into place and is flush with the surface of the case.
4. **Camera Control Button:** Gently press the button into its slot until it sits flush with the surface of the case. When installed correctly, it will produce a tactile click and respond smoothly to zoom and control inputs.



## Test Fitment

**Test Button Functionality:** Press each button to ensure it has a clear, tactile response. If a button feels 'mushy,' adjust its position until you feel a distinct click with each press.



## Logo Installation

1. **Prepare the Logo:** Take the logo piece and ensure it is clean and free of debris.
2. **Locate the Logo Slot:** Find the opening at the bottom of the case designed for the logo.
3. **Insert the Logo:** Position the logo correctly over the opening and press firmly from the inside of the case to secure it in place.
4. **Ensure a Flush Fit:** Check from the outside that the logo sits flush with the case's surface and there are no gaps.


## Routine Inspection and Maintenance:

- Our phone cases with preinstalled components are designed to withstand normal daily use without issue. However, we advise customers to periodically check these components to ensure they remain secure. Should any parts become loose or detach, please remove them immediately to prevent choking hazards and contact our support team at [Support@phonerebel.com](mailto:Support@phonerebel.com) for assistance.



# Camera Lens Installation Guide

F



Installing your Phone Rebel camera lens is a straightforward process. Follow these steps to ensure a secure and proper fit:

## 1. Prepare the Camera Lens and Case

- Ensure the camera lens is clean and free of fingerprints or dust.
- Locate the camera cut-out on your Phone Rebel case, where you will find notches that match the slots on your camera lens.

## 2. Align the Camera Lens (Refer to image F)

- Carefully align the lens with the camera cut-out on the case. The thinner side should be positioned at the bottom, as indicated by A in Figure F. If the lens is placed incorrectly, the screw holes will not line up with the holes on the case.
- Once aligned, gently place the lens into the cut-out.

## 3. Secure the Lens with Screws (Refer to image G)

- Your camera lens comes with six small screws that fit into the corners and centers of the lens.
- Using a PH00 screwdriver, Begin by securing the top-center and bottom-center screw first, making sure to hold the lens firmly in place. Tighten each screw gradually.
- Once all screws are in place, finish tightening each until snug. Avoid over-tightening to prevent damage to the lens or case.


## 4. Dispose of the Screwdriver Safely

- After installation, it is recommended to dispose of the small left over screwdriver to prevent any safety risks or choking hazards. Ensure it is out of reach of children and properly discarded according to local regulations.

## 5. Final Inspection

- After all screws have been securely tightened, inspect the lens to ensure it is flush with the case and there are no gaps.
- Check that the lens cover does not obstruct the camera's view and that all camera functions operate correctly.

G



By following these steps, your Phone Rebel camera lens will be securely installed and ready for use. For any issues during installation or if you require assistance, please contact our support team at [Support@phonerebel.com](mailto:Support@phonerebel.com).

### **Child Safety Warning:**

- While Phone Rebel products are not designed for children's use, our phone cases come with preinstalled small components that could pose a choking hazard. It is the purchaser's responsibility to ensure that these components do not present a risk, particularly around children.

### **For Customers Purchasing Removable Components Separately:**

- If you're buying accessory components, we recommend keeping them out of children's reach and ensuring they are properly installed and secured:
- **Buttons/Camera control button:** Test for proper installation by checking for a tactile click. If the buttons feel "mushy," reseal them to ensure they're correctly positioned.
- **Logos:** Install from the inside of the case, pushing firmly to guarantee a flush fit against the case's back.
- **Lens Rings:** Accompanied by small screws. Regularly check and tighten these screws as necessary. After installation, dispose of any left over screws to prevent any safety risks.
- **Installation Tips:**
- Make sure all components are correctly oriented and seated. For buttons, a proper installation will result in a clear, tactile response. Logos should fit seamlessly into the case, and lens rings should be securely fastened with their screws.

For further guidance or if you have any concerns about the safety of small components, please reach out to our support team at [Support@phonerebel.com](mailto:Support@phonerebel.com).