

Operation Manual

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA



  
**SPYCRUSHERS**

[www.spycrushers.com](http://www.spycrushers.com)

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

### BEFORE YOU BEGIN

#### **IMPORTANT NOTE: Prohibition against eavesdropping**

All jurisdictions have specific laws and regulations relating to the use of cameras and video recorders. Before using any camera or video recorder for any purpose, it is the buyer's responsibility to be aware of all applicable laws and regulations that prohibit or limit the use of such products and to comply with the applicable laws and regulations.

#### **PACKAGE CONTENTS**



- SpyCrushers Car Key Chain Spy Camera
- 4GB SD Card
- Mini USB Cable

### SPYCRUSHERS CAR KEY CHAIN CAMERA LAYOUT



#### Operating Instruction

##### Turning The Car Key Chain Spy Camera On

- Insert the 4GB SD Card into the device (this must be inserted in order to function properly)
- Press the On/Off button and then release it.
- The yellow status light indicates the device is now in standby mode and ready for video recording and photo taking.

##### Turning The Car Key Chain Spy Camera Pen Off

- Press and hold the On/Off button for 2-3 seconds. The yellow status indicator light will flash repeatedly 2- 4 times. The Car Key Chain Spy Camera will shut down saving all video and photo files automatically.
- The Car Key Chain Spy Camera will not switch off if you do this while the Car Key Chain Spy Camera is in video mode and recording.
- If the Car Key Chain Spy Camera is recording you must press the Video/Camera button once to stop recording and return to standby mode then press and hold the On/Off button until the yellow light flashes repeatedly and the device will then shut down saving all video and photo files automatically.

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

### Video Recording

- To record video turn on the Car Key Chain Spy Camera. Once on, press and hold the Video/Camera button until the indicator light flashes repeatedly 3 times and stops. You are now recording video. To stop recording simply press the Video/Camera once quickly.

### Taking Photos

- To take photos turn on the Car Key Chain Spy Camera. Once on, press the Video/Camera button once quickly, the indicator light will flash once taking one photo. Repeat process to take more photos.

### Connect To Your Computer

- While the Car Key Chain Spy Camera is off or in standby mode it can be connected to your computer using the USB Cable. Plug the USB Cable connector into the Car Key Chain Spy Camera and the other end into your computer. The Car Key Chain Spy Camera will be listed as a "Removable Disk". Within two files folders will hold images or video. Once connected the Car Key Chain Spy Camera will upload its data to your computer, the yellow status indicator light will blink quickly. To disconnect safely please click "Safely Remove Hardware and Eject Media" icon on the right bottom corner of your task bar. Then click the "Eject" choice and unplug the USB cable from both your computer and Car Key Chain Spy Camera.

### Charging

- Connect the Car Key Chain Spy Camera to your computer using the USB Cable. When the battery charging you will see the yellow status indicator light blinking slowly. The battery is fully charged when the yellow light stops blinking. **Note:** If the yellow indicator light continues to blink after 120 minutes disconnect and use normally. The Car Key Chain Spy Camera can be charged at anytime, but for maximum battery life please use battery until completely drained and fully recharge to its capacity for the first five times.

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

### Car Key Chain Spy Camera As A PC WebCam

- Turn on the Car Key Chain Spy Camera and connect the device to your computer using the USB Cable. Press and hold down the Video/Camera button for 6-10 seconds and release. Use and enjoy.



### Setting The Time And Date Stamp

- Connect the Car Key Chain Spy Camera to your computer. Under the Devices and Removable Storage Directory click on and open the "Removable Disk" or the name that represents the Car Key Chain Spy Camera on your computer. Right click inside the white space and go to "New" then click and create a 'Text Document'. Name the text file "Time" and save. Open Time.txt and type the date and time in this format: yyyy-mm-dd hh:mm:ss Y. Therefore, fifteen seconds past 2:02pm on December 25th 2012 would be written as: 2012-12-25 14:02:15 Y. Note the use of 24-hour time and the Y stands for "Yes display time" a "N" after would stand for "No do not display time". Ensure you save your changes. Remove the Car Key Chain Spy Camera from the computer and turn on the Car Key Chain Spy Camera. Pictures and videos will now be time stamped with the updated date and time.

### Reset

- To reset the SpyCrushers Car Key Chain Spy Camera back to its original manufacture settings use a toothpick or non-metal pointed object to push the reset button. Do not use metal objects. Metal objects may damage the SpyCrushers Car Key Chain Spy Camera and should be avoided. This will not reset the time or delete any files. Use the reset button only if the SpyCrushers Car Key Chain Spy Camera is not responding.

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

### Technical Specification

Subject	Technical Specification
Video Resolution	720x480
Video Format	AVI
Video Frame Rate	30fps±1fps
Video Player	The Recording file is comply with all Major video player
Image Scaling	4:3
Photo Format	JPEG
Photo Resolution	JPG 1280 x 1024
Support System	Windows ME/2000/XP/2003/Vista/7
Charging Voltage	DC-5V
Interface-Type	USB 2.0 Port -Standard
Memory	Removable 4GB SD Card Included
Battery Type	Rechargeable High-Capacity Polymer Lithium Battery (280mah)
Recording Time	Approx 2 hours

### Cautions

- a) **Battery:** As the usage time grows, the battery life will shorten. Please recharge battery to its full capacity before using after long periods of inactive use.
- b) **File Security:** The SpyCrushers Car Key Chain Spy Camera is not a dedicated storage device. SpyCrushers does not warrant the completeness and safety created files. Please back-up the important files onto your computer or other storage device.
- c) **Video Quality:** The SpyCrushers Car Key Chain Spy Camera is not professional grade video recorder or camera. SpyCrushers makes no assurance that the video or photo quality will meet your particular standards.
- d) **Operating Temperature:** 0—40°C\_
- e) **Operating Humidity:** 20%—80%. Please do not use this product at above normal humid environment. The SpyCrushers Car Key Chain Spy Camera is not water resistant or water proof.

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

- f) **Filming:** In order to protect the optics within from the hard light please do not expose lens directly to sunlight or other strong or harsh lighting sources for long periods.
- g) **Cleaning:** Please only use lens paper or soft eye cloth to clean camera lens.
- h) **Durability:** The SpyCrushers Car Key Chain Spy Camera is a precision electronic product. Please do not use around high magnetic fields or high electric fields.

### Warranty Information

SpyCrushers brand and all SpyCrushers products are owned and operated by Crushers, Inc. Crushers, Inc warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labor or replaced at the sole discretion of Crushers, Inc.. The end user is responsible for all freight charges incurred to send the product to Crushers Inc's repair centers. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of purchase. The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void. By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

Crushers Inc.

info@crushersinc.net

© Crushers Corporation Communications 2013

# SPYCRUSHERS CAR KEY CHAIN SPY CAMERA

## Operation Manual

### FCC Verification

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

**Connect, friend and follow SpyCrushers for product specials, discounts, secret surprises and more. See you on the inside!**

<http://www.facebook.com/spycrushers>

<http://www.twitter.com/spycrushers>

<http://www.youtube.com/user/spycrushers>