
Welcome to the Pool-Mate Pro User Manual



Contents:

Pool-Mate Pro watch USB pod USB lead Instruction manual Quickstart/overview guide

Quick Start

When using the Pool-Mate Pro for the first time the pool length, your weight and the hand you wear the Pool-Mate Pro on, must first be set. The default settings are 25m, 65KG and left handed.

From main CLOCK screen

Press Mode 4 times to show SETUP, select by pressing Start.

Set watch from metric to imperial units if required by pressing Up/Down


Set Pool length by pressing Up/Down until correct value is shown

Press Mode 3 times to set your weight (again use Up/Down to select correct value).

Press Mode once to set left or right hand (use Up to select).

Hold Start for 2 secs to return to main menu and Mode to return to CLOCK screen

You are now ready to Swim!



Swimming

- Press Start to begin
- Swim your session
- Hold Start for 2 seconds to stop.


Press Up and Down to view Laps. Strokes, Distance, Calories, Efficiency Index and Time.

To record sets:


- Press Start- swim first set
- Press Start to Pause (a P will appear at the start of the bottom line and the time for your last set will remain for 3 seconds the reset so you can time your rest period).
- Press Start again to Restart- swim next set.
- Repeat as required
- Hold Start for 2 secs to Stop

The Pool-Mate Pro must be put into Pause Mode when drilling or kicking.

To conserve battery life, if the watch has NOT been PAUSED and no laps have been detected for 5 minutes, the watch will stop recording and return to CLOCK screen.



Selecting your settings



*Changing swimmer: The Pool-Mate Pro has been designed so up to to 3 swimmers can share one watch or families with more than one watch can use the same PC to analyse their swims. In either case each swimmer should be assigned a number (1, 2, or 3). The swimmer should set the assigned number on the watch in the SETUP menu before swimming and change his weight.

Setting the Time

Setting the Alarm

Start

From ALARM SET in the SETUP menu Press Start - the hours will flash on the clock display, press Up and Down to ALAPM change value. Press Mode to select minutes, pressing Mode again selects on SEE or off. Press Up and Down to change value as before.

> Hold Start for 2 secs to return to SETUP. Hold Start again for 2 secs to return to main menu.



select Hours. Minutes. on/off

Up to change Down

change

Setting the Alarm to ON activates the bell icon, above seconds on the display.

The alarm will sound each day at the set time for one minute or until Mode is pressed.



Start

From TIME SET in the SETUP menu Press Start - the hours will flash on the clock display, press Up and Down to change value. Press Mode to select minutes, pressing Mode again will select Year, then month, then date, then 12/24 hour setting, press Up and Down to

Hold Start for 2 secs to return to SETUP. Hold Start again for 2 secs to return to main menu.



Mode

select Hours, Minutes, Year, Month.Date 12/24hr

change values as before.




hold for 2 secs to Hold EXIT Start

Reviewing your sessions on the watch

Previous Session

Data can be viewed after swimming directly from the CLOCK screen by simply using the *Up/Down* buttons to scroll though Laps, Average Strokes per lap, Distance, Speed (seconds per 100m or yards), Calories, Efficiency and Time.



Other sessions

From CLOCK screen press Mode twice to go to LOG

Press *Start* to enter. Use *Up* and *Down* to scroll through recorded sessions (the Pool-Mate stores each session in the log by number and date).

Press Start to view selected log details.

Use *Mode* to scroll through the TOTALS for this session - Swimming time (without rest periods), Laps, Distance, Calories and Average Strokes.

Any SETS can then be viewed. Scroll through SET Time, Laps, Distance, Average Strokes, Speed, Efficiency Index with *Mode*.

Hold Start to exit

Deleting files

All sessions are automatically stored in the LOG however you can delete individual sessions you do not want to save.

Select the Log file you wish to delete then press Mode. ERASE will flash at the top of the screen. Press Mode, SURE will appear press Mode again to delete the selected file.

NOTE: once erased you will lose this file and it will not be recoverable.

CHRONO

Chrono

Start

SEŁ

00:00m

TIP: To see how specific SWIM icon indicates a Swim log. Start metrics vary between No SWIM icon indicates a Chrono log sets (Time, Speed etc) Select required metric (eg Time) with Mode Up SELECT and scroll through Sets REQUIRED with Up/Down. The metric will be shown LOG Down for each set so you can

Use Mode to scroll

through TOTAL Time.

Laps, Distance,

Calories and Average

Strokes.

compare.

Use *Mode* to scroll through SET Time, Laps, Distance, Strokes per lap, Speed and Efficiency Index.

Chrono


CLOCK

rs nac



SETS





SEE2 TA

10:56 m

From CLOCK screen press *Mode* to go to CHRONO Press *Start* .

Cet 1 will about an

Set 1 will show on the display

As when Swimming, pressing *Start* again will PAUSE, another press will RESTART and the Set count will increment.

A long press will STOP.

The session can be viewed in exactly the same way as swim sessions- using Up/Down immediately after the session or from the LOG screen. Chrono files are distinguished from Swim files as the SWIM icon will not show.

NOTE: In Chrono mode the motion sensor will not operate- only ${\sf Time}\, is\, {\sf recorded}$ -not ${\sf Speed}\, or\, {\sf Distance}.$

view **Elapsed** time and **Actual** time

Use Mode to

1. Your Pool-Mate Pro has been designed for lap swimming in a pool. It has not been designed to work in Open Water.

START BUTTON:

Aquick press will START.

Afurther press will PAUSE.

A long press will STOP.

Another press will RESTART

Start

TOTALS

- 2. The Pool-Mate Pro detects regular stroking patterns that conform to FrontCrawl, BreastStroke, BackStroke or Butterfly strokes only, the Pool-Mate Promust be put into PAUSE mode when doing drill and kick sets.
- 3. Strokes must only be changed at the end of a lap, not part way through a lap or inaccurate lap and stroke counts may be recorded
- **4.** The stroke count displayed is the number of strokes taken by the arm you wear the Pool-Mate on. Remember when swimming FrontCrawl and BackStroke this is half the total number of strokes.
- 5. Like most sports watches, the buttons are not designed to be operated underwater. You must make sure the Pool-Mate Pro is out of the water before pressing any buttons. Do NOT dive in wearing the Pool-Mate Pro. Pressures are much greater and water may be forced into the case.

Efficiency

The Efficiency Index is calculated from the distance travelled per stroke and time per stroke. This index decreases as your efficiency increases. less than 30 Excellent -Ellie athlete

30-40 Very Good 40-50 Above average 50-70 Average more than 70 Below average

Replacing the battery

The Pool-Mate Pro's battery (CR2025) has an estimated life expectancy of over 12 months. The higher your average hours swimming a week, the shorter the battery life will be. To maintain water resistance and ensure the warranty remains valid, the Pool-Mate Pro should be returned to Swimovate Ltd for battery replacement or taken to a qualified watch maker- do not attempt to change the battery yourself.

Care and maintenance

The Pool-Mate Pro is water resistant to 50m, however the buttons are not designed to be operated underwater. You should make sure the Pool-Mate Pro is out of the water before pressing any buttons. Do not dive wearing the watch. The Pool-Mate Pro should not be used if any fogging or water droplets appear inside the watch. Never attempt to dismantle or service your Pool-Mate Pro yourself.

Always protect your Pool-Mate Pro from shocks, hard and sharp objects, extremes of heat and prolonged exposure to direct sunlight.

If not in use, store your Pool-Mate Pro in a clean, dry environment at room temperature. Do not store in a damp environment such as a sports bag.

Do not expose to strong chemicals and cleaning products as they may damage the Pool-Mate Pro's seals, case and finish.

If your Pool-Mate Pro needs cleaning, wipe it with a soft damp cloth. Mild soap may be used if necessary. The Pod and lead are not water resistant and should not be placed in contact with water.

Warranty

No guarantee is given as to the accuracy of the watch or it's lap and stroke counting ability with particular swimmers or strokes. If this product should fail due to defects in materials or workmanship. Swimovate Ltd will repair or replace it free of charge for a period of twelve months from the date of purchase (proof of purchase required). This warranty is only extended to the original purchaser and covers failures due to defects in materials or workmanship that occur during normal use. It does not cover battery, battery replacement, damage or failures resulting from neglect, accident, misuse, mishandling, alteration or modifications of the product or any failure caused by the operation of the product outside the scope of its published specifications. Swimovate Ltd shall in no event be liable for any incidental or consequential damages arising from the use or inability to use the product. Swimovate Ltd do not assume any responsibility for losses or claims by third parties that may arise through the use of this product. If a claim under warranty appears to be necessary email support@swimovate.com (or telephone +44 (0)1784 481562) to obtain a returns number before returning your Pool-Mate Pro. Packages will not be accepted without a returns number.

Certification-The Pool-Mate Pro has CE and FCC approvals.

The CE mark is used to mark conformity with the European Union EMC directive 89/336/EEC.The Pool-Mate has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This User Manual and its contents are intended solely for the use of our customers to obtain knowledge regarding the operation of the Pool-Mate Pro.The contents shall not be disclosed or reproduced without the prior written consent of Swimovate Ltd. Great care has been taken to ensure the accuracy of this documentation but it's contents are subject to change at any time without notice. The latest version of this documentation can be downloaded from www.pool-mate.com.

Copyright © 2010 Swimovate Ltd







prool mate

Automatic Swimming Computer with PC Link

Manual

v1.00

Software Installation

8.1 Download the installers from www.swimovate.com/downloads.html

The software consists of three programs:

- Driver for the USB pod. Important: Must be installed before connecting the pod
- Pool-Mate Link. Downloads your data from the pod to your computer.
- Pool-Mate Pro application. Shows the data on your computer.

The driver and link are supplied in a single archive (PoolMateSetup.exe) and the PC software in another. Download both archives to your computer. The PoolMateSetup.exe is suitable for XP, Vista or Windows 7 but you will need to download the appropriate version of the Pro application for your operating system.

8.2 Run PoolMateSetup.exe by double clicking on it. The Driver and Link software will be extracted to C:\PoolMateSetup.

8.3 Install the driver software

Go to C:\PoolMateSetup\USBdriver and double click setup.exe.

Follow the instructions and click on accept the license. The driver will be installed for you.

Connect the pod to a spare USB port using cable provided and place on a flat table. The computer should detect the new device and complete installation of the driver. This may take a minute or two.

8.4 Install the link software

Go to C:\PoolMateSetup\PoolMateLink and double click setup.exe. Follow the instructions to install.

8.5 Install the PC software

Double click setup.exe in the PC software archive and an installer will take you through the installation process.

The link and PC applications can be added to your startup folder so they are automatically loaded when you need them.

You can now transfer your data from the Pool-Mate Pro!

Upload from watch

9

9.1 Run the link software (Program files/Swimovate Ltd/Pool-Mate Link). Plug your pod into your computer via the cable.

An icon will appear in the system tray in the bottom right of your screen. Hover your mouse over the icon and the Pool-Mate pod name will be shown and a COM port number.



Press Mode 3 times on your Pool-Mate Pro to select UPLOAD.

Turn your watch over so it is facing downwards and place gently in the pod making sure the Pro logo on the pod is aligned with the Pro logo on the watch and both have the same orientation (the watch does not need to be pressed hard into the pod).

After a short period the download will automatically start and progress shown by the system tray icon.



The data is checked to make sure it has been received correctly.



9.2 Run the PC application (Program files/Pool-Mate Pro) and view your data! See section 10.

NOTE- Each time you download data from your watch you need to run the link software, download your data, then run the PC software!

FAQs and troubleshooting

THE SOFTWARE

Q My data won't upload?

A Check you have selected UPLOAD on your Pool-Mate Pro, it is lined up correctly in the pod and your pod is connected to a spare USB port.

Make sure you have run the Link software and the icon appears in the system tray. Hover your mouse over the icon and the Pool-Nate Pod name will be shown e.g. Pool-Mate port:COMxx (where xx is the port number). If no Port number is shown please contact support.

The Pro logos on the watch and the pod should be aligned so the Infrared transmitter and receiver are lined up. The Pod also needs to be on a flat surface or upload won't commence.

Q Do you support 3rd party developers?

A We would like other software developers to add Pool-Mate support in their applications. Please email info@swimovate.com for more details.

THE WATCH

Q How does the Pool-Mate Pro work?

A The Pool-Mate Pro contains state of the art motion sensors that detect the motion of your arm. Our unique software algorithms and digital signal processing techniques analyse the data and extract lap, stroke, distance, speed and calorie information automatically.

Q Do I need to press a button at the end of each lap like other lap counters?

A No, The Pool-Mate Pro is fully automatic and will sense when you start a new lap without you having to do anything.

Q Why do I need to enter my weight?

A The Pool-Mate Pro uses this to work out the calories you expend.

Q I want to swim sets, can the Pool-Mate Pro record each set?

A Yes, you can record all the details from individual sets as well as the details of the total swim session.

Q The Pool-Mate Pro doesn't count all my laps

A If you have inaccurate lap results make sure the watch is securely attached to your wrist and can't move around. Also try gliding for a longer period at the start of each lap. This saves you energy and gives the Pool-Mate Pro a little longer to register the change of laps. Some swimmers may find better results wearing the Pool-Mate Pro on the other wrist.

Q The Pool-Mate Pro doesn't work when I'm doing kick sets or some drills.

A The Pool-Mate Pro must be put into Pause mode when kicking or drilling.

Q Will the Pool-Mate Pro work in Open Water?

A The Pool-Mate Pro has been designed for lap swimming in a pool and this version will not work in Open Water.

Q Can I wear the Pool-Mate Pro on my right arm?

A Yes, the Pool-Mate Pro will work on either wrist, just change the setting in the SETUP menu.

Q The Pool-Mate Pro gives strange results when I change strokes mid lap.

A The Pool-Mate has not been designed to recognise changes of stroke part way through a lap. If you are going to change strokes you must do it when you change laps. If a hesitation or interruption in the stroke pattern occurs mid lap this may also cause inaccurate lap counts.

Q What does the efficiency index measure?

A The efficiency index is based on the recognized Swim Golf method that you may be familiar with. It is the number of strokes plus the time taken to swim 25 metres. Concentrate on reducing this number to increase your efficiency and improve your swimming.

Q What units is the Speed measured in?

A We have found that the time to swim 100 metres (or yards) is more of a meaningful measure of swimming speed than metres per second or miles an hour as swimmers are used to watching the pool clock and judging speed from it. The Speed shown is the average time in seconds per 100 metres if set to metric units, or yards if set to imperial units.

Q Will the Pool-Mate Pro work with tumble turns?

A Yes, the Pool-Mate Pro will work with both tumble turns and when pushing off the wall.

Q How accurate is the Pool-Mate Pro?

A The watch has been tested on a wide variety of swimmers over an 18 month period prior to launch. We have a 99.75% accuracy rate with our database of thousands of laps from many swimmers with 1500m times of between 22 and 40 minutes. No guarantee is given for accuracy with individual swimmers and rates may differ with users whose strokes or abilities differ from the norm.

Q Will the watch work with all pools?

A The watch will work with pools over 15m in length. It just needs setting to the pool length before use. In order to recognise you are swimming, the watch needs to detect several swim strokes, if using a small pool you may reach the end before this occurs if this happens the watch wont record laps correctly, we recommend you try a larger pool. Best results will be found in pools over 20m.

For other support issues please email support@swimovate.com

Please register your purchase and we will keep you updated with tips, offers and upgrades.

http://www.swimovate.com/register.html

For further details and latest software please see the website

www.pool-mate.com



10

Once you have followed the steps overleaf to install the software and upload your data you are ready to run the PC software. NOTE- you must run the Link software each time you want to add new data from your watch first.

10.1 Run the Pool-Mate Pro software (Program files/Pool-Mate Pro/Pool-Mate Pro.exe). The first time you do this a screen will appear asking you to choose your language and default unit, click the correct settings. You will then be asked to input a swimmers details- put in your details and click the green tick box then close.

10.2 Click the download icon (second from the left)

Click on open file to add new data from your Pool-Mate Pro once you have uploaded it. A dialog box will appear with progress and feedback.

Close this screen and your latest data will appear on the main screen.

The main screen below will appear and ask you to record your first swim.

