TRIPLE C

POWER CARD MANUAL GUIDE

INSTRUCTION

Charging the Power Card:

Press the status indicator button, located on the side of Power Card to see how much power remains.

Your Power Card uses a rechargeable battery. Fully charge your Power Card before using.

Use the included USB charging cable to connect to any computer or power adapter.

Please refer to LED charging chart. Charging time is approximately 3 hours.

Charging your device:

Use your finger to slide the metal USB cover up. It will raise up like shown in video to right. Push the metal USB cover back down into the flat storage position when not in use. Use the USB charging cable which comes with your device (iPhone, iPod, mobile phone etc.) and plug it in to the USB connector on the Power Card. Press the status indicator button.

Your device will begin to charge. After 30 seconds of unplugging your device, the Power Card will automatically turn off. Push the metal USB cover back down into the flat storage position when not in use. The Power Card can not be charged while charging your phone or other device.

CAUTION:

It is normal for the Power Card to get a little hot while charging

The Power Card should be well ventilated when charging to avoid overheating which will reduce the charging efficiency and life of the battery.

Do not leave the Power Card directly in the sun or rain. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.