

Both the Pro and Runner turf come with 2 rubber tees. The putting cup & flag is an accessory which can be purchased from TheNetReturn.com

Lift the corner of the turf and find the mark you just created with your scissors. Use the black marker to highlight the location.



YGU'LL NEED:

- Drill with 3/8" bit
- Utility Knife
- Tape Measure
- Scissors
- Black Marker

RUBBER TEE:

Get situated where you feel most comfortable hitting your Driver (traditionally this is about 8 to 8 1/2 feet back from the front of the net). Mark the location at the end of your Driver using the scissors. Use enough pressure on the scissors so that you can see a mark on the back of the turf.






Using your drill with the 3/8" bit, drill the hole for your rubber tee starting from the back of the turf.

PUTTING CUP:



Cut out the paper putting cup template, which we will use to cut the hole for our putting cup.

The putting cup template is on a separate page.



Fold the rubber tee in half, feeding it through the hole. If at first it doesn't fit, take the drill and expand the hole a little more, making sure it's still a nice and snug fit. You have now successfully installed the rubber tee.



Flip the turf upside down and place the cut-out where you want your hole. We recommend 4 to 5 inches from the edge of the turf opposite your rubber tee, centered on the turf. Use a tape measure to ensure accuracy.





Use the black marker to trace the template; with the utility knife carefully cut out the hole.



Flip the turf over and start putting. Note: If you purchased the putting cup and flag accessory (3 pieces), continue with steps 6 and 7.



Trim off any residual nylon with your scissors, creating a clean hole.



The bottom piece of the cup snaps in underneath your turf.



The blowfish slides onto the bottom of the plastic flag pole, which connects into the hole located in the center of the cup.



You have successfully installed the putting cup and flag.

