

IMPORTANT SAFETY INSTRUCTIONS

PLEASE RETAIN FOR FUTURE REFERENCE

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision. This item is not to be used for hospital or medical use.

Read all instructions before use.

KEEP AWAY FROM WATER.

DANGER- As with most electrical appliances, electrical parts are electrically live when the switch is off.

To reduce the risk of death by electrical shock:

- a. Always unplug the appliance after use.
- b. Never use while bathing.
- c. Never place the appliance near water or other liquid.
- d. If the appliance falls into water unplug it immediately never reach in the water to get it.
- e. Never use the appliance if the cord is damaged or twisted or bent.

WARNING - To reduce the risk of burns, electrocution, fire or injury to persons:

- 1. This appliance should never be left unattended when plugged in. Turn it off by the switch and unplug the electrical cord from the mains.
- 2. This appliance should only be used for its intended use as described in the manual.
- 3. Never operate this appliance if it is damaged or has a damaged cord or plug. If it is not working properly or if it is dropped in water or damaged in any way. Return this item

to a service centre for examination or repair. **NOTE:** Beauty Hair does not have any authorised service centres. If this appliance is still under warranty please call: 0208 365 1300.

4.Keep the cord away from hot surfaces. Never twist or wrap the cord around the appliance.

5.Never use while sleeping.

6.Do not use outdoors.

7.This cap is hot when in use. Do not let eyes or bare skin touch the heated surfaces.

8.Do not place on any surface while the appliance is hot or plugged in.

9.Do not use an extension cord with this appliance.

10.Do not use a voltage converter with this appliance.

11.Do not use folded.

12.Do not insert pins.


CORD SAFETY

1.Never pull or yank the cord.

2.Always inspect the cord before each use.3.Never wrap the cord around the appliance.DO NOT OPERATE THE APPLIANCE IF THE CORD

SHOWS ANY SIGN OF DAMAGE OR IF THE APPLI-ANCE WORKS INTERMITTENTLY OR STOPS WORK-ING COMPLETELY.

> What's in the box 1. Conditioning cap. 2. Instructions.



INSTRUCTIONS FOR USE

About your Hair Conditioning Cap

The cap is perfect for professional conditioning treatments without having the drying effect of hair dryers. It can soften the hair as well as making it more manageable helping to restore hair damage caused by relaxing and styling abuse.

This cap is especially effective when used with A.P.H products like Olive Oil Steaming Conditioner.

To Condition Your hair.

1. Apply an apple amount of conditioner to your hair. (Your hair can be slightly damp or dry)

2. Cover your hair with a plastic shower cap this is to help keep the Heat Cap clean. (Plastic cap sold separately)

3. Fasten chin strap by pressing the chin strap button and pushing the button toward your chin.

4. Plug in the Heat Cap(Make sure your hands are completely dry before plugging or unplugging the Heat Cap.

5. Adjust the control switch to the desired temperature.

6. Leave the cap in place for 10-30 minutes. (Leaving the cap on for longer than 30 minutes is not recommended.

7. Once you have finished your treatment remove from your head.

8. Unplug the cap.

9. Wash and style hair as desired.

Cleaning

Unplug the Heat Cap and allow it to cool before attempting to clean it. **NEVER IMMERSE THE HEAT CAP IN WATER OR ANY OTHER LIQUID.**

Use a soft slightly damp cloth to wipe any part of the cap that needs cleaning.

Storing your cap

- * Always allow your cap to cool before storing it.
- * Never store your cap while plugged in.
- * Never wrap cord tightly around the cap.
- * Never fold or crush the cap when storing it.
- * Never hang the cap by its power cord.