

# Assembly Instructions

## 24 Inch Wide Cart



TOPWC62


### Step 1

Fully insert **Caster Adapters** into sockets on the bottom of the **Panel**, then insert **Casters** into **Caster Adapter** slots




### Step 2

Insert **Internal Leg Connectors** into sockets on top of the **Panel**



### Step 3

Fully insert **24 Inch Legs** into sockets on the bottom of additional **Panel**




### Step 4

Place second level over first level, inserting **Internal Leg Connectors** into legs




### Exploded View




### Items List



Internal Leg Connector



Caster



Caster Adapter



24 Inch Leg



Panel

### Step 5

Repeat

Repeat Steps 2 through 4 for each additional shelf level  
(Requires TOPWC62A Add-On Shelf)

Complete