

COTTON All 1 - 2 Camera & Binocular Harness Instructions

Thank you for your purchase of a CCS G3 Harness, our best in class designs do not compromise fit, functionality or form. Our goal is single minded, to provide secure camera carrying systems that free your hands, keep your equipment safe and your body mobile, Ready To Shoot Now!





2. Use the Shoulder Tightening Straps to ensure the Harness is snug and comfortable. Balance with waist to ensure the weight of your camera is distributed evenly.



3. The Shoulders are adjustable from the inside. Larger or shorter individuals can take off the Harness and re-adjust the velcro straps to whats comfortable.



1. Fit the Camera Harness by pulling the

Speed Straps EVENLY, ensuring the unit

rests mid torso as shown.

is tightened snugly on your body. Harness

4. Ensure you align the arrow of the Camera Hub in direction of the lens.




6. Attach the Side Holster to the Camera Harness using the Velcro Wraps. Alternatively, you can attach the Side Holster to your belt or the waist strap of your backpack.



CAREFUL: putting the arrows the wrong way will put your camera at risk of falling out of the Harness.

Patended Twist& Lock System



FASTEN





If you have and questions or comments feel free to call or email us @ info@cottoncarrier.com 1-877-852-9423

www.cottoncarrier.com



5. Insert the Camera with Camera Hub at 90 Degrees into the Harness Receiver. Resting with the lens down the camera will lock in with our Patented Twist& Lock System.



7. Attach the Camera Tethers from the Camera Harness D-Rings to the HIGH IMPACT Split Rings on your camera. (splitring included with the Camera Hub)

Features:

Rain Cover: A self-containing bag that quickly comes up and over the camera protecting it from water damage.



Stash Pocket: Simple pocket on the front of the Harness for storage of small items.



Located on the back of the Harness for small to medium sized storage



Binocular Users Strap velcro around lens and attach tether to threaded loop

Lens Stabilization Strap: A strap that holds the lens snug against the body while active. (eg. biking, skiing, climbing, running.)



Inside Stash Pocket: Inside pocket for storage of small items.

Visit our YouTube page for video instructions **3 Year Warranty**: we offer a 3 year technical warranty on all of our harness systems

Be sure to share your stories and photos with us!

f 🛛 🗲 🖫 #HarnessYourPhotography