



Futura X

Wireless Charging Pad

User Guide



Input port



BEZEL Wireless charging area



LED indicator

QUICK START OPERATION

1



Plug standard USB end of cable into power adapter (not included).

* 5V/2A USB adapter recommended for faster charging.

2



Plug micro-USB end of cable into Futura X input port.

LED indicator will display a burst of white light when charger is connected to power source.

3



Place mobile device (phone or tablet) level in center of charging pad. Note device must have a built-in Qi wireless charging receiver or accessory Qi-enabled case/patch.

LED indicator will glow to confirm charging is underway.

PACKAGE CONTENTS

Futura X Wireless Charging Pad
Micro-USB Cable
User Guide

SPECIFICATIONS

Input	5V / 2A
Output	5V / 1A
Charging Distance	≤ 8mm
Charging Efficiency	≥ 73%
Dimensions	95 x 95 x 7 mm (3.7 x 3.7 x 0.27 inch)

SAFETY & HANDLING INSTRUCTIONS

1. Keep wireless charging unit dry and away from liquid.
Do not use on wet surfaces.
2. Don't attempt to dissemble or modify charger.
3. Always disconnect power supply before cleaning charger.
4. Keep away from high heat. Use in the temperature range between 0 and 45 degrees Celsius (32 and 113 degrees Fahrenheit).



THANK YOU FOR YOUR ORDER!

Learn more about BEZALEL and our full line of
wireless charging products at bezalel.co
Contact us at support@bezalel.co