BMW S1000 RR


Children Battery Powered Trike



Owner's Manual with Assembly Instructions

Made in China.

The owner's manual contains important safety information as well as assembly, use and maintenance instructions. The Ride-on must be assembled by an adult who has read and understands the instructions in this manual. Keep the packaging and bags away from children and dispose of all packaging properly before use. Keep this manual for future reference.



PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

We will be happy to correct any problems that you may have, or answer any of your questions regarding the purchase of this product. Please contact us at our Toll Free customer service number 1-800-599-8898 for any assistance and replacement parts. Please keep your sales receipt which may be request when seeking assistance.

Thank You.

Dist. by TDC USA, Inc. Fairfield, NJ 07004

©2021 All Rights Reserved.

Made in China.

Item 60775

www.tdcusainc.com

This ride-on car will provide your child with many miles of riding of enjoyment. To help assure you and your rider a safe ride we ask you to please read this manual carefully, and keep it for future reference.

Follow the recommendations in this manual, they are designed to improve the safety and operation of your ride-on car and it's rider.

1 YEAR LIMITED WARRANTY SIX MONTH LIMITED WARRANTY ON BATTERY

6-months warranty applies only to the 6-volt battery which is included by TDC USA Inc. with the vehicle when it was originally purchased. This warranty covers normal use and does not cover the vehicle or battery if damaged by unreasonable use, neglect, abuse, accident, misuse, improper service or other causes not arising out defects in material or workmanship. Evidence of any attempt at consumer repair will void this warranty.

Conditions of warranty:

- . The user assumes all risk of personal injuries, damage to, or failure of the Vehicle and any other losses if the Vehicle is altered in any way or if the Vehicle is used for stunt riding, ramp jumping, aerobatics or similar activities, or is towed by another person or vehicle.
- This warranty does not cover ordinary wear and tear, damage caused by improper storage of Vehicle, shipping damage, damage caused either accidentally or deliberately by you or another, and damage caused as a result of using the Vehicle other then for its intended purpose.

BMW S1000 RR Children Battery Powered Trike manufactured by Zhejiang Jiajia Ride-On Co., Ltd. (Add: Xincang Industrial Zone, Pinghu City, Zhejiang Province, P.R.China). The BMW logo and the BMW word mark are trademarks of BMW AG and are used under license.

SPECIFICATIONS

Age	18-36 Months
Weight Capacity	Max 40lbs
Speed	Max 1.5 mph
Overall Dimensions	26" x 14.57" x 17.32"
Charge Time	8-12 hours
Battery	6V 4Ah
Charger	6V 500mA

A WARNING!

CHOKING HAZARD - Small parts. Not suitable for children under 36 months. The product contains small parts, keep children away when assembling.


ADULT ASSEMBLY REQUIRED.

• Always remove protective material and poly bags and dispose before assembly.

· Assembly tools required:



2X AAA Batteries * (Steering Wheel)







Approximate
Assembly Time:
30 Minutes

SAFETY

THE FOLLOWING SAFETY HAZARDS MAY RESULT IN SERIOUS INJURY OR DEATH:

- This product contains small parts. Keep children away during assembly. Make sure to remove all packaging material and parts from underneath the vehicle body.
- Never open the battery. Batteries contain lead and lead compounds (acids) that are toxic and corrosive, and known to the state of California to cause cancer and reproductive harm.
- Limbs, hair, and clothing can get caught in moving parts. Always wear shoes, keep limbs away from moving parts, and do not wear loose clothing while operating this vehicle.
- This vehicle does not have brakes or braking capability. Do not leave a child unattended during operation. Do not use this in a location that may require braking capability, as this could result in loss of control, which may cause serious injury or death.
- Use of this vehicle in unsafe conditions such as snow, rain, loose dirt, mud, sand, or gravel may result in an unexpected accident such as tipping over, and could damage the electrical system or battery.
- Do not operate this vehicle in an unsafe manner. Examples include but are not limited
 to:
 - Pulling the vehicle with another vehicle or similar device
 - Allowing more than one rider
 - Pushing the user
 - Traveling at an unsafe speed

BATTERY WARNINGS

THE FOLLOWING SAFETY HAZARDS MAY RESULT IN SERIOUS INJURY OR DEATH:

- Use of a battery charger other than the supplied 6V rechargeable battery and charger may cause a fire or explosion. Only use the supplied battery and charger.
- Use of the 6V rechargeable battery and charger for any other product may result in overheating, fire, or explosion. Never use the supplied rechargeable battery and charger with another product.
- Explosive gases are created during charging. Charge the battery in a well-ventilated area. Do not charge the battery near heat or flammable materials.
- Contact between the positive and negative terminals may result in fire or explosion. Avoid direct contact between the terminals. Picking up the battery by the wires or charger can cause damage to the battery and may result in a fire. Always pick up the battery by its case or handles.
- Liquids on the battery may cause fire or electric shock. Always keep all liquids away from the
 battery and keep the battery dry. Contact or exposure to battery leakage (lead acid) may cause
 serious injury. If contact or exposure occurs immediately call your physician. If the chemical is
 on the skin or in the eyes, flush with cool water for 15 minutes. If the chemical was swallowed,
 immediately give the person water or milk. Do not give water or milk if the patient is vomiting or
 has a decreased level of alertness. Do not induce vomiting.
- Battery posts, terminals, and related accessories contain lead and lead compounds (acid) chemicals known to the state of California to cause cancer, reproductive harm, and are toxic and
 corrosive. Never open the battery
- Tampering or modifying the electric circuit system may cause a shock, fire or explosion and
 permanently damage the system. Exposed wiring and circuitry in the charger may cause electric
 shock. Always keep the charger housing closed.
- Do not mix old and new batteries.
- Do not mix alkaline, stand (carbon-zinc) or rechargeable batteries.

A USER WARNINGS


THE FOLLOWING SAFETY HAZARDS MAY RESULT IN SERIOUS INJURY OR DEATH:

- · Never leave a child unattended.
- · Always sit in the seat when using this vehicle.
- Keep your hands, hair, and cloths away from moving parts.
- · Always wear shoes when operating this vehicle.
- · Only one rider is allowed on the vehicle at a time.
- · Children under 18 months of age cannot use this vehicle.
- Only drive on level ground.
- Do not go near swimming pools or other bodies of water, drop-offs or up and down steep inclines.
- Do not drive the vehicle into loose dirt, mud, sand, fine gravel, or on wet surfaces.
- Do not drive the vehicle on streets or near cars.

PART NO.	PART NAME	QUANTITY (PCS)
1	Vehicle Body	1
2	Face Guard	1
3	Handle Bar	1
4	M5x35 Machine Screw	1
5	Ø5 Nut	1
6	Charger	1
7	Gear Box	1
8	Rear Wheel	2
9	Ø8 Washer	3
10	Lock Nut	1
11	Front Wheel Assembly	1
12	Spanner	2
13	Rear Axel	1




NOTE: Some parts shown are assembled on both sides of vehicle




Remove all the parts from the rear axle. Turn the vehicle body upside down.


- 1. Slide a Ø8 Washer (9) onto the Rear Axle (13).
- 2. Slide a Rear Wheel (8) onto the Rear Axle (13).
- 3. Plug the connector on the vehicle into the connector on the **Gear Box (7)**.
- 4. Slide rear axle through the hole on the **Gear Box (7)**, (ensure the driving wheel match up with the gear box), and out through the hole on the other side of the vehicle body.




- 5. Slide a Ø8 Washer (9) onto the Rear Axle (13).
- 6. Slide a Rear Wheel (8) onto the Rear Axle (13)
- 7. Slide another **Ø8 Washer (9)** onto the **Rear Axle (13)**.
- 8. Tighten a Lock Nut (10) to the end of the Rear Axle (13) with a Spanner (12).

HINT: AN EXTRA SPANNER HAS BEEN PROVIDED TO HOLD THE LOCK NUT ON THE OTHER SIDE OF THE REAR AXLE WHILE TIGHTENING THE LOCK NUT ON THE OTHER SIDE.





- 1. Plug the light wire connector on the **Face Guard (2)** into the connector on the vehicle.
- 2. Insert the tabs on the Face Guard (2) into the slots on the vehicle.



- 1. With a screwdriver remove the **Screw** on the **Battery Cover** on the **Face Guard (2)**.
- 2. Remove the **Battery Cover** from the top of the **Battery Compartment**.
- 3. Insert two **AAA batteries** in their correct polarities.
- 4. Replace the **Battery Cover** over the **Battery Compartment** and fasten with the **Screw** you removed in step one.

Connect the Power Supply



- 1. Using a screwdriver to remove the screw on the **Seat** back.
- 2. Remove the **Seat**.
- 3. Plug the **Vehicle Connector** into the terminal on battery as shown above.
- 4. Replace the seat.
- 5. Using a screwdriver replace the screw on the **Seat** back.

A WARNING!

PREVENT INJURIES AND DEATHS:

- NEVER LEAVE CHILD UNATTENDED. DIRECT ADULT SUPERVISION IS REQUIRED. Always keep child in view when child is in vehicle.
- This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
- · Protective equipment should be worn.
- Never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water.
- · Always wear shoes.
- Always sit on the seat.
- Not to be used in traffic.
- This toy is unsuitable for children under 18 months due to its maximum speed; Maximum user weight is 40 lbs.
- This toy has no brake.

RULES FOR SAFE RIDING

- · Keep Children within Safe Riding Areas:
 - Never use in roadway, near motor vehicles, on lawn space, on or near steep inclines or steps, swimming pools or other bodies of water;
- Use the toy only on flat surfaces. Such as inside your house, garden or playground.
- Never use in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or a well-lit area.
- · It is prohibited to change the circuit or add other electric parts
- Inspect wires and connections of the vehicle periodically.
- \cdot $\;$ Do not let any child touch the wheels or be near them when the car is moving.








Use the vehicle on generally level ground ONLY!

DO NOT Use the vehicle on Lawn space!



- 1. **Sounds Buttons:** Press to play sounds.
- 2. **Foot Pedal:** Applies power (speed) to the vehicle.



- 1. Plug the charger port into the input socket (the socket is at the back of the vehicle.)
- 2. Plug the charger plug into a wall outlet. The battery will begin charging.

A WARNING!

This product with **Charging Safety Protection:** when charging, all functions will be cut off! Only an adult can charge and recharge the battery!

M WARNING!

PREVENT FIRE AND ELECTRIC SHOCK:

- Use the only rechargeable battery and charger supplied with your vehicle.
 NEVER substitute the battery or the charger with another brand. Using another battery or charger may cause a fire or explosion.
- Do not use the battery or charger for any other product. Overheating, fire or explosion could occur.
- NEVER modify the electric system. Tampering with the electric system may cause a shock, fire or explosion or may permanently damage system.
- Do not allow direct contact between battery terminals. Fire or explosion can
- Do not allow any type of liquid on the battery or its components.
- Explosive gases are created during charging. Do not charge near heat or flammable materials. Charger the battery in a well-ventilated area ONLY.
- NEVER pick up the battery by the wires or charger. Damage can occur to the battery and may cause a fire. Pick up the battery by the case ONLY.
- · Charge the battery in a dry area ONLY.
- Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.
- Do not open the battery. Battery contains lead acid and other materials that are toxic and corrosive.
- Do not open the charger. Exposed wiring and circuitry inside case may cause electric shock.
- Only adults may handle or charge the battery. NEVER allow child to handle or charge the battery. Battery is heavy and contains lead acid. (electrolyte).
- Do not drop the battery. Permanent damage to the battery could occur or cause serious injury.
- Before charging the battery, check for wear or damage to the battery, charger, its supply cord and the connectors. DO NOT charge the battery if any damage to parts has occurred.
- Do not allow the battery to drain completely. Recharge the battery after each use or once a month if not used regularly.
- Do not charge the battery upside down.
- Always secure the battery with the bracket. Battery can fall out and injure a child if vehicle tips over.

The POWER SWITCH must be turned in OFF position when charging.

Before the first use, you should charge the battery for 4-6 hours. Do not recharge the battery for more than 10 hours to avoid overheating the charger.

When the vehicle begins to run slowly, recharge the battery.

After each use or once a month minimum recharge time as 8 to 12 hours, less than 20 hours at most.

The battery features a thermal fuse with a rest fuse that will automatically trip and cut all power to the vehicle if the motor, electric system or battery is overloaded. The fuse will reset and power will be restored after the unit is turned OFF for 20 seconds and then turned ON again. If the thermal fuse trips repeatedly during normal use, the vehicle may need repair. **Contact your distributor please.**

TO AVOID LOSING POWER, FOLLOW THESE GUIDELINES:

- Do not overload the vehicle.
- · Do not tow anything behind the vehicle.
- · Do not drive up steep slopes.
- Do not drive into fixed objects, which may cause the wheels to spin, causing the motor to overheat.
- Do not drive in very hot weather, components may overheat.
- Do not allow water or other liquids to come in contact with the battery or other electric components.
- Do not tamper with the electric system. Doing so may create a short, causing the fuse to trip.

BATTERY DISPOSAL





Recycle the dead battery responsibly. The battery contains lead acid (electrolyte) and
must be disposed of properly and legally. It is illegal in most areas to incinerate lead
acid batteries or dispose of them in landfills. Take it to a federal or state-approved
lead acid battery recycler, such as local automotive battery retailer. Do not throw the
battery away with your regular household waste!

Problem	Possible Cause	Possible Cause	
	Battery low on power	Recharge battery. After each use, or once a month minimum, charge the battery for a 'full' 8 to 12 hours. DO NOT leave the battery on the charger for more than 20 hours.	
Vehicle Does not run	Thermal fuse has tripped	Replace thermal fuse with new fuse. (See thermal fuse)	
	Battery connector or wires are loose	Check that the battery connector is firmly plugged into the motor connector.	
	Battery is dead	Replace battery. Please call us at 1-800-599-8898 for battery replacement.	
	Electrical system is damaged	Check to see if water may have corroded the system. Loose dirt, gravel or sand might have jammed the switch.	
	Motor is damaged	Please call us at 1-800-599-8898.	
Vehicle Does not run very long	Battery is under charged	You may not be charging the battery long enough. After each use, or once a month minimum, charge the battery for a 'full' 8 to 12 hours. DO NOT leave the battery on the charger for more than 20 hours.	
Loud grinding or clicking noises coming from motor or gear box	Motor or gears are damaged	Please call us at 1-800-599-8898.	
Vehicle runs sluggishly or beeping occurs	Vehicle is overloaded	Reduce weight on vehicle. Do not overload the vehicle. Only one rider at a time. Maximum user weight is 40lbs.	
	Vehicle is being used in harsh conditions	Operate the vehicle on level ground and firm surfaces.	
Vehicle needs a push to go forward	Poor contact of wires or connectors	Check that the battery connector is firmly plugged into the motor connector. If wires are loose around the motor please call us at 1-800-599-8898.	
	"Dead Spot" on motor	A dead spot means the electric power is not being delivered to the terminal connection and the vehicle needs repair. Call us at 1-800-599-8898.	
6V Battery will not recharge	Battery connector or adapter connector is loose	Check that battery connectors are firmly plugged into each other	
	Charger not plugged in	Check that battery charger is plugged into a working wall outlet	
Battery bubbles or gurgles when charging	This is normal and not a cause for concern		
Charger feels warm when recharging	This is normal and not a cause for concern		

- It is parents' responsibility to check main parts of the toy before using.
 Regular examination of transformer or battery charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, toy must not be used with the transformer or battery charger until such damage has been repaired.
- Make sure the plastic parts of the vehicle are not cracked or broken.
- · Park the vehicle indoors or cover it with a tarp to protect it from wet weather.
- Keep the vehicle away from sources of heat, such as stoves and heaters.
 Plastic may melt.
- Recharge the battery after each use. Only an adult can handle the battery.
 Recharge the battery at least once a month when the vehicle is not being used.
- Do not wash the vehicle with a hose. Do not wash the vehicle with soap and water. Do not drive the vehicle in rainy or snowy weather. Water will damage the motor, electric system and battery.
- Clean the vehicle with a soft, dry cloth. To restore shine to plastic parts, use a non-wax furniture polish. Do not use car wax. Do not use abrasive cleaners.
- Do not drive the vehicle in loose dirt, sand or fine gravel which could damage the moving parts, motors or the electric system.
- When not using, all the electrical source should be turned off. Turn off the power switch and disconnect the battery connection.

BMW S1000 RR

Children Battery Powered Trike

Dist. by TDC USA, Inc. Fairfield, NJ 07004 ©2021 All Rights Reserved. Made in China. Item 60775

Questions and Comments 1-800-599-8898 (9 am - 5 pm EST) www.tdcusainc.com