





HAMMOCK WITH CARRY BAG

USER INSTRUCTIONS - 706926/23682




STEP 1:

Wrap a Harness around a sturdy object, such as a tree.




STEP 2:

Pull the end of harness with multiple loops throughout, through the end of harness with a single loops.




STEP 3:

Pull the Harness as tight as possible around your sturdy object so that there is no slack between the harness and object.



STEP 4:

Attach Carabiner to loop on Hammock and to one of the multiple loops on Harness that has passed through the single loop on Harness.



SAFETY STATEMENTS AND WARNINGS



1. Tools are NOT required for assembly of this product.
2. Always inspect the Hammock, Harnesses, and Carabiners carefully before each use. DO NOT USE IF ANY PARTS ARE SHOWING SIGNS OF WEAR OR TEAR.
3. Small children should not use the Hammock unsupervised.
4. Pets should not be allowed into the Hammock as it may result in personal injury or damage to the product.
5. DO NOT exceed the recommended weight capacity of 260 lbs.
6. Excessive swinging and other rough play may result in personal injuries.
7. Take your time getting into and out of the Hammock. The Hammock may tip if your weight is not centered.

CARE


1. To extend the life of the product and the materials its made of, reduce direct sunlight as much as possible when not in use.
2. Keep your Hammock in the Carry Bag and store in a cool and dry location. Limiting the Hammock's exposure to the elements will extend the life of the product.
3. To clean, wipe with a damp cloth and let it air dry completely before stowing it away.

HAMACA CON BOLSA DE TRANSPORTE


INSTRUCCIONES PARA EL USUARIO - 706926/23682




PASO 1:
Coloque un arnés alrededor de una estructura firme, tal como un árbol.



PASO 2:
Tire del extremo del arnés con varios lazos a través del extremo del arnés con un lazo sencillo.



PASO 3:
Tire del arnés hasta apretarlo tanto como sea posible alrededor de la estructura firme, de forma tal que esté lo más tenso posible y no se afloje el lazo de la estructura.



PASO 4:
Enganche el mosquetón al lazo de la hamaca y a uno de los lazos en el arnés que pasó a través del lazo sencillo en el arnés.

INFORMACIÓN DE SEGURIDAD Y ADVERTENCIAS

1. NO se necesitan herramientas para el montaje de este producto.
2. Inspeccione siempre con atención la hamaca, los arneses y mosquetones antes de cada uso. NO LO UTILICE SI CUALQUIER PIEZA PARECE ESTAR DESGASTADA O ROTA.
3. Los niños pequeños no deben usar la hamaca sin supervisión.
4. No se debe dejar subir a las mascotas a la hamaca ya que podrían causar lesiones personales o dañar el producto.
5. NO debe sobrepasar la capacidad de peso recomendada de 260 libras.
6. El columpiarse en exceso y los juegos bruscos pueden causar lesiones personales.
7. Tómese tiempo para subirse y bajarse de la hamaca. La hamaca puede voltearse si el peso no está centrado.

CUIDADO

1. Para extender la vida útil del producto y de los materiales que lo componen, reduzca la exposición a la luz solar directa todo lo posible mientras no lo use.
2. Mantenga la hamaca en la bolsa de transporte y guárdela en un lugar fresco y seco. Limitar la exposición a la intemperie prolongará la vida útil del producto.
3. Para limpiar, usar un paño húmedo y dejar secar al aire por completo antes de guardar.