


## **Outdoor Storage Box - Instructions**

Item # 22518

## STEP 1


Fix the Front Panel and Back Panel onto the Bottom Panel.



\*Note: Place the flat side upright.


## STEP 2

Fix the Right Panel and the Left Panel with the bottom, front, and back panels.





## STEP 3

Insert the three Bolts through the hinges of the Back Panel to connect the Lid with this part. Connect a Lid Strut to either side of the Lid and to the right and left panels.




**STEP 4** Fix the two Wheels to the Wheel Frames.





Insert the ends of the Bottom Panel found underneath the Right Panel into the groove of the Wheel Frame.



Place the two holes on the Wheel Frame over the plugs underneath the Bottom Panel.