



Adjustable Base WiFi Adapter Setup Guide

Part 1: Remote App Control



Initial Setup

Apps to Download

Ananda Base Wifi

Apps for Voice Command

Amazon Alexa

or
 Google Home + Google Assistant

Items Required

- **Phone/tablet:** Set WiFi to 2.4G (non 5G connection)
- **Adjustable Base with WiFi Adapter**
- **Voice Command Only:** Alexa/Google Home device with account (Set WiFi to 2.4G, non 5G connection)
-Most devices compatible-

WiFi Adapter Disconnection

(this step is only needed for split sets who want synced movements)



Pair WiFi Adapter with "Ananda Base WiFi" for Remote App Control

1 Register on the "Ananda Base WiFi" App.
(2 registrations/logins will be required for split sets who want their beds to operate independantly).


2 Next press the Foot-up & Foot-down buttons for 5 seconds on the remote.
The blue LED light on the WiFi adapter will flash and beep every 3 seconds.



3 Open the WiFi settings interface on your phone.
Select the WiFi with the name "KeesonAp-xxxxxxx".




4 Open the "Ananda Base WiFi" App. Select the menu button. Select "All the Beds" option. Then select "Connect New Beds".



5 Select the Home WiFi name that the WiFi adapter will connect to. Input the WiFi password, then select "Done". Once the WiFi adapter makes the "Beep-beep" sound, the connection is complete. (If incorrect password is entered you will need to restart from step 2)



6 Return to the "New Bed" screen in the App and wait for the ID to be displayed, this may take up to 2 minutes. Click the ID number then select "Ok" to complete the connection. Make sure your phone is using the same WiFi as the adapter.
NOTE: If you see a 'Bind Failure' Warning, just click the ID number again.



For Voice Command Setup Continue to Part 2.



Adjustable Base WiFi Adapter Setup Guide

Part 2: Voice Command (Smart Device Required)




Amazon Alexa Devices


***Make sure your Alexa device is set to a 2.4G WiFi connection, if you have not done so already follow these steps.**

Open the Alexa app > Go to Settings > Select the Alexa device that will pair with your bed > Select Change WiFi Network & follow the prompts.

- 1 **Open the Amazon Alexa App.** Search for "South Bay Smart Base skill" in the Alexa Skill Store and enable it.



- 2 **Enter email & password.**
EMAIL: same email as used in the "Ananda Base WiFi" App
PASSWORD: same password as used in the "Ananda Base WiFi" App



- 3 Alexa and the WiFi adapter need to be set to the same LAN & use the same WiFi. **First, you need to give the command: "Alexa, ask my base to find device."** Once your bed finds and connects to your device move on to the next page.

***SPLIT SETS WHO WANT THEIR BEDS TO MOVE INDEPENDANTLY PLEASE NOTE THE FOLLOWING:**

*You will need: 2 Amazon accounts, 2 Alexa devices, 2 WiFi adapters and to repeat the steps for Alexa voice command setup.
You also need to name your Alexa devices a different name, such as "Alexa" and "Echo".*




Google Home Devices


***Make sure your Google Home device is set to a 2.4G WiFi connection, if you have not done so already follow these steps.**

Open the Google Home app > Select the Devices button in the top right hand corner > Select the Google Home device that will pair with your bed > Select Settings and make sure your router is broadcasting a 2.4G signal is selected.

- 1 **Open the Google Assistant App.** Search for "South Bay Base" action and select "Talk to Power Base". Then select "Link".



- 2 **Enter email & password and select app.**
EMAIL: same email as used in the "Ananda Base WiFi" App
PASSWORD: same password as used in the "Ananda Base WiFi" App



- 3 Once your bed finds and connects to your device, use the invocation phrase **"Hey Google, Talk to Power Base"** to start the bed action. Then move on to the next page.

***SPLIT SETS WHO WANT THEIR BEDS TO MOVE INDEPENDANTLY PLEASE NOTE THE FOLLOWING:**
(GOOGLE HOME IS NOT COMPATIBLE AT THIS TIME)

Start off any Alexa device command by saying **"Alexa, tell my base to ..."** or **"Alexa, ask my base to ..."**.
For Google Home use **"Hey Google, tell my base to ..."** or **"Hey Google, ask my base to ..."** prior to any command below.



Contact our comfort concierge at 1-855-726-2632 for a full list of commands