ZEITMESSER



## How to setup your timepiece



- O1 Remove the lock from the crown.
- To set the <u>correct time</u>, pull the crown to position 3 and turn it until the correct time is displayed.
- To <u>set the date</u>, push the crown in by one position so that it is in position 2. Turn the crown clockwise until the correct date is displayed. Now you can push the crown back to the starting position (position 1).

Note: Your date changes at noon? This is because the movement does not "know" if it is noon or midnight. If so, simply wind your timepiece forward by 12 hours.

ZEITMESSER



## How to setup your timepiece



To set the second time zone (GMT), leave the crown in position 2, but turn it counterclockwise to the correct hand position.

Note: Are you wondering how to read the second time zone? This is indicated by the yellow GMT hand, just like on a single-hand watch. On the outer ring of the dial you will find 24-hour markers. This way you can easily read off the time.