

# ProofCam

The firmware update is designed to load onto your Dash Cam the latest firmware/software which incorporates any new features and/or fixes any bugs.

## **Instructions:**

- Download the files to your computer – do not open them at any point during this process. Then copy them on to a blank SD card. You can use the SD card in you Dash Cam and just delete both the “Event” and “Normal” folder before copying the firmware file onto it.
- Making sure the Dash Cam is turned off, and connected to power, insert the SD card and turn on the Dash Cam.
- Follow the on screen instructions. Let the Dash Cam process and go through the six stages without interruption.
- Remove the SD card and delete all the files before re-inserting.