S/MBLY



dining table 01



Attach leg support B to table top (A) by aligning dowels with holes in table top. Locate holes in B, insert allen wrech and rotate to lock.



Slot leg pieces C and D into support (B) and align pins with slots in table top. Locate holes in C and D, insert allen wrech and rotate to lock. Turn over and enjoy!





S/MBLY



©2019 Simbly Furniture. All rights reserved.