


\_\_\_\_\_\_Use



Aroma Diffuser

User Manual

User Manual

# Operation



Lift up the cover.



Add the right amount of water (not exceeding the MAX line) and a few drops of essential oil into the water tank.



Put the cover back on, connect the included AC adapter to the DC port at the back, and then plug the AC adapter into the home power supply socket.

4.

Maintenance

#### LIGHT button

Press once to turn on the light and it begins to cycle through colors.

The color will change per press. Long press to turn off the light.

Aroma Diffuser

User Ma



#### IIST Button

1st press – turn on and set 1 hour mist working time
2nd press – set 3 hours mist working time
3rd press – set continuous mist
4th press – turn off mist
Long press for 3s to turn off the mist

# Specification

Dimensions	110*130mm
Input	AC 100-240V 50/60Hz
Output	DC 24V 500mA
Length of power cord	150cm
Electric consumption	10W
Time mode	1H / 3H / ON
Water tank capacity	150ml
Materials	ABS+PP

Aroma Diffuser

User Manual

Aroma Diffuser

# Troubleshooting

After-sale Service

Email: support@innogear.net

Phone: 800-806-3008

Is there enough water in the tank?  -Add enough water but do not exceed the MAX line. Is the AC adapter connected correctly?  -Please unplug, check and re-plug correctly.
Not enough water or too much water?  —Add the right amount of water but do not exceed the MAX line.  Dust on the ultrasonic film?  —Clean the product according to the maintenance.  Dust on the air intake?  —If the air intake is dirty, mist won't come out. Just clean it.
Is there any crack at the bottom of the water tank?  —Please check if there is any tiny crack at the bottom of the diffuser through which water can leak. If you find a crack upon receipt of this product, please contact us for a free replacement.  Is steam water inside the cover wiped out?  —Wipe out steam water after each use, making sure the inner cap is completely dry before refilling in case steam water may leak out while putting cover back on.  Low temperature or high humidity?  —In this case, mist may condense quickly into water drops.

This product is guaranteed for 12 months from the date of purchase,

please contact us if you need a replacement/refund.

Aroma Diffuse

User Manu

### FAQ

- Q: Why can't I find the power adapter upon receipt of this product?
- A: The power adapter is packed in the water tank of diffuser. Please lift up the cover to find it.
- Q: Why can't I smell anything?
- A: The strength of scent from different essential oils may vary. Choose a strong scented oil and don't put the diffuser near the air conditioner, fan or window.
- Q: Can the light be set for one specific color only?
- A: Yes. Just press the LIGHT button.
- Q: Can I turn the light off and just use the mist?
- A: Yes. There are separate buttons for the light and the mist.


#### Precaution

- The power adapter is packed in the water tank of diffuser. Please lift up the cover to find it.
- To prolong the life span of the diffuser, do not use mineral water.
- Do not fill water over 150ml.
- Due to anti-dry protection, the diffuser will stop misting when the water is lower than a certain level.
- Do not touch the Ultrasonic vibration plate when using.
- Unplug the unit before maintenance and clean regularly with damp clean cloth.
- Do not fill water directly. Please add water with cup (not included).
- Keep away from direct sunshine heat sources and air conditioners or fans.
- Always keep on flat, moisture-resistant surface. Do not place on carpet, duvet or unstable area.
- Keep away from electronic equipment, such as TV and other auto equipment.
- Do not flip the unit when in operation, otherwise water may enter the mechanism and cause malfunction.
- Please clean the product before changing to another scent of essential oil according to the instructions.
- Please only use 100% essential oil with this diffuser. Low quality oil that contains chemicals, spices, or impurities may cause malfunction.

Aroma Diffuser

Please clean the product as following steps after using 5-6 times (or 2-3 days):

- Turn off the power, unplug the power cord and remove the cover.
- Pour out all the remaining water in the basin from the DRAIN SIDE.
- Add a few drops of neutral kitchen detergent into warm water and clean the product with a soft rag.






Aroma Diffuser

# Accidental Leakage

If the unit happens to be knocked over or tipped during operation, please follow the steps to avoid malfunction.

- Turn off the power, unplug the power cord and remove the cover.
- Pour out all remaining water in the tank from the DRAIN SIDE.
- Shake the unit to drain the water inside the mechanism, and put it in a well-ventilated place for natural drying.



Follow us on Facebook



www.facebook.com/InnoGear.net

Aroma Diffuser

Aroma Diffuser

Arc