



Ermetika[®]
INSIDE WALLS




SETUP INSTRUCTION

Evokit


Standard equipment



Tools




Overall view






INDEX

| | |
|-----------------------------|-------|
| Setup for 100 finished wall | 3-6 |
| Setup for 125 finished wall | 7-10 |
| Setup plasterboard | 11-13 |



1.1







1.2



1.3




1.4




Subject to misprints, errors and technical modifications.
All dimensions are in mm


2.1



2.2




2.3





Subject to misprints, errors and technical modifications.
All dimensions are in mm




2.4





2.5



3.1






3.2





Subject to misprints, errors and technical modifications.
All dimensions are in mm

3.3



3.4



PAINT



T. +39 (0)883535781



info@ermetika.it



www.ermetika.it



www.youtube/ermetika.it