

M A L M

INSTRUKTIONSMANUAL / INSTRUCTION MANUAL

DALTON

- ① MINUTVISARE
MINUTE HAND
- ② TIMVISARE
HOUR HAND
- ③ SEKUNDTVISARE
SECOND HAND
- ④ VRIDNING
BEZEL
- ⑤ 24 H VISARE
24 H HAND
- ⑥ DATUM
DATE
- ⑦ START/STOPP KRONOGRAF
START/STOP CHRONOGRAPH
- ⑧ NOLLSTÄLL KRONOGRAF
RESET CHRONOGRAPH
- ⑨ MINUTVISARE KRONOGRAF
CHRONOGRAPH MINUTE HAND
- ⑩ SEKUNDTVISARE KRONOGRAF
CHRONOGRAPH SECOND HAND




FUNCTIONS

SET TIME & DATE


SET DATE

First of all, unscrew the crown to unlock it, Then pull out the crown to its first (1st) position. Turn the crown clockwise to set the date. Press and screw down the crown back to its normal position.
*Do not set the date between 21,00 and 03,00 as this will cause the date to not work properly.



SET TIME

First of all, unscrew the crown to unlock it, Then pull out the crown to its second (2nd) position. Now turn the crown clockwise or counterclockwise to set the time. Press and screw down the crown back to its normal position



SCREWED DOWN CROWN


To ensure that the crown by mistake hooks out of position and reset the time, the crown is screwed down in its normal position. The screwed down crown also serves as a seal against moisture and water, therefore it is very important that the crown is screwed down properly during use.



CHRONOGRAPH


START CHRONOGRAPH

Push the top button (pusher) to start the chronograph. The center positioned second hand shows elapsed seconds while the subdial shows number of elapsed minutes (and hours depending on your movement).




STOP CHRONOGRAPH

When you push the top button (pusher) one more time the chronograph stops,




RESET CHRONOGRAPH

Push the lower button (pusher) to reset and return the chronograph to zero. The hands return to its original positions.



TOTAL RESET

- ① First of all, unscrew the crown to unlock it. Then pull out the crown to its second (2nd) position
- ② Push the lower button (pusher) for 2 seconds, then release.
- ③ Push and screw down the crown back to its normal position.
- ③ If your watch is equipped with a small second hand it will move at 2 seconds interval for 10 seconds as a demonstration.



SPECIFICATIONS

CASE

MODEL

DALTON/CATALINA/WHITEFOX/PEGASUS, 41 mm, 316L Stainless steel

ACE, 44 mm, 316L Stainless steel

CONSTRUCTION

Solid, cast middle case, screwed down crown, screwed case back


DIMENSIONS (mm)

2-8(Ø):	41,00	44,00
12-6:	50,00	51,00
Tot. height:	13,00	14,25
Dial opening:	32,00	34,50
Lugs width	20,00	22,00

GLASS

Scratch proof sapphire, glareproofed coating, coating to prevent fingerprints and marks.

WATER RESISTANT



MOVEMENT

MODEL

SEIKO VK63A/VK64/VK67

CONSTRUCTION

A combination of a quartz movement and mechanical movement. Current time are powered by battery (quartz) while the chronograph is powered by mechanical technique.

DIMENSIONS (mm)


Outside (Ø):	30,80
Tot. height:	5,10
Distance (small) hands center pos.:	7,50

FUNCTIONALITY

Precision/Deviation: +/- 20 sec/month

Battery life: Ca 3 years

Recommended temperature: -5°C to +50°C



MAINTENANCE

USE

Your MALM chronograph from is a watch designed with the greatest care and love for materials, quality, design and performance. At MALM, we believe in the importance of producing quality watches and therefore spend much of our time on product development and quality assurance.

When using your MALM chronograph, the watch will be exposed to different types of stresses and strains. Like many other advanced watches and gauges, within a very small volume a large number of components contribute to handle all the functions. It is therefore important that you take care of your watch and do not expose it to unnecessary and abnormal stress. The watch should be serviced regularly and should always be pressure tested after a battery replacement. Such services should always be performed by MALM or by a watchmaker for warranty terms to apply.

Navigation related calculations and other general calculations can be performed using the chronograph along with the bezel. These calculations should be seen as approximate references and a complement to more reliable, digital calculations.

GOOD TO KNOW

The daily use of any wrist watch may result in scratches and marks over time. This is considered to be a natural result of wear and tear. There are various recommendations as to whether these scratches and marks can be polished. We recommend that you always contact MALM or a watchmaker before trying this on your own. Though regular cleaning with a soft damp brush will keep your watch clean and shiny.

If you wear your watch with MALM's leather straps, it is good to be familiar with the aspects that shorten the life of genuine leather products. Even though MALM's leather straps are of the highest quality, like other leather products, they will have varying length of life depending on how they are used and cared for over time. Water, cosmetics and sweat, for example, shortens the life of your leather strap.

Like other valuable items you should treat your MALM watch with great care. It is important that you do not expose the watch to unnecessary impacts, chemicals, solvents, hazardous gases or magnetic fields. Your MALM watch is designed to work smoothly between -5°C and $+50^{\circ}\text{C}$.

WATER RESISTANCE

Water resistancy in watches are mostly measured in ATM (atmosphere). Your MALM chronograph watch is waterproof up to 10 ATM, that is 100 meters / 328 feet. In practice, this means you can shower and swim with the watch. However, you should not use the watch for diving since 100 meters do not refer to 100 meters of water depth.

CONDENSATION

In case of fast and high temperature variations, a so-called negative pressure may occur in your watch. A possible consequence of this is that condensation occurs. If condensation occurs, there is liquid or moisture inside the watch (which you may not see). In case of condensation, the watch must be handed in immediately to MALM or a watchmaker whom then will open the watch and remove the liquid and / or the moisture. If you choose not to open your watch, moisture may penetrate the movement and destroy it. The warranty does not cover damages caused by condensation as this is not due to any manufacturing defect. Even divers watches are not protected against condensation. Typical occasions when condensation can occur are, for example, in saunas, ice baths and activities in strict cold environments.

DISPOSAL

The consumer plays an important role in reducing the risk of handling electrical waste and electronic equipment such as batteries and accumulators. Some batteries, accumulators and components used in electronic equipment may contain hazardous substances that can cause damage to the environment and endanger human and animal health unless properly disposed of. If you can not reuse your battery it should be discarded at a council or recycling facility.

WARRANTY

1. These terms apply to your purchase of, and the use of, your MALM watch. The terms are an agreement between you and MALM Watch Group AB (hereinafter referred to as "MALM" or "we"), org. nr 559091-3829. By making a purchase of a MALM product you agree to the following terms and conditions. We therefore ask you to carefully read the following terms.

2. Your watch from MALM are warranted with 5 years from the day it was first purchased by its original purchaser and upon proof of purchase. The warranty covers errors and deficiencies arising from the manufacturing process regarding parts as the watchcase, dial, hands, glass, strap and movement. The warranty gives you the right to receive free repairs and returns in accordance with the terms and conditions that are stated and within the warranty period.

3. This warranty is subject to following exclusions and limitations:

- The product is damaged because of inappropriate use or negligence (bruises and marks on the products, dents, broken glass and so on).
- Damages caused by fire, water or natural disasters,
- Natural aesthetic changes caused by normal use or aging (scratches, changing of the color of the strap, or other marks).
- Change of battery.
- Costs concerning international shipping and phone calls.

4. Please note that MALM will charge a fee for repair and service for those warranty claims that fall within the scope of exclusions and limitations.

5. If you purchased your MALM product through an authorized MALM dealer, please contact them regarding questions about warranty and warranty claims. If you purchased your MALM product via malmwatches.com, please contact us via the provided contact

form at malmwatches.com or send an email to support@malmwatches.com and we will provide you with more information about how to proceed. Please write your name, address, order number and a detailed description of your warranty issue in your message. Please write "Complaint of purchase" as the title. To use the warranty, it requires that you have access to your purchase receipt, an order confirmation or and/or an order number.

6. Whatever the reason for return, it is very important that the product is packaged so that it can not be damaged during transport. Incorrect products returned to MALM should still be treated with care by the customer and as if they were new and flawless.

7. If your claim falls within the scope of our warranty terms, the damaged product or part/parts will be repaired or replaced within a reasonable time after we have received the product. MALM always strives to replace damaged parts with new, original parts, but reserves the right to replace damaged parts with equivalent parts if the original is not available. If a particular product is no longer available, the customer is entitled to choose a similar product or repayment instead.

8. If MALM does not find any of the errors mentioned above, the product will be sent back to you.

9.0 If there is a dispute between you as a customer and MALM watches, and we are unable to resolve the dispute, you can send a complaint to the EU Dispute Resolution Online. More information can be found at their website.

10. MALM's liability for defects in connection with delivery is limited in accordance with the applicable delivery terms for the current delivery and what follows from these terms. MALM's liability to you for any

losses or damages is limited to the total amount of your product. MALM has no liability for indirect losses.

11. Regulatory information, certifications and compliance with standards relevant to the products are available on the product and/or in the packaging.

12. This warranty is in lieu of any other express warranties, obligations or liabilities.

13. This warranty may not limit any legal rights that apply to you as a customer. Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary by state to state.*

*US only

MALMWATCHES.COM