


Setting the Single-Hand Classic DayClock

Before starting, insert a AA battery.

Locate the two dials on the movement above the battery compartment.


Step 1

Gently pull out the smaller dial at the top center of the movement. Turn the dial to rotate the day hand to the approximate time. Push the dial back in.



Step 2

Turn the large dial at the lower right of the movement to make fine adjustments to the day hand. For precision, we suggest calibrating the fine adjustment at noon or midnight.



For additional assistance please contact DayClocks Customer Service:
info@dayclocks.com or 1-866-DAY-CLOC (329-2562).