


Setting the Three-Hand Combination DayClock

Before starting, insert a AA battery.

Locate the two dials on the movement above the battery compartment.


Step 1

Rotate the large dial to align both the hour and the minute hands to 12.




Step 2

Gently pull out the small dial. If the current time is before noon, rotate the day hand to the line next to yesterday and if it's after noon select the line next to tomorrow. Push the small dial back in.



Step 3

Rotate the large dial so the hands move clockwise for AM settings or counter clockwise for PM settings to the current time.



For additional assistance please contact DayClocks Customer Service: info@dayclocks.com or 1-866-DAY-CLOC (329-2562).