

 ambrane




CHARGE BEYOND WIRES!

AEROSYNC PB 10

10000mAh

**WIRELESS POWERBANK WITH
MAG-SAFE COMPATIBILITY**

 **made in india**

USER MANUAL

Welcome

Thank you for purchasing the Ambrane AeroSync PB 10 power bank. We recommend you to read the instruction manual carefully before using the product.

Package Contents

- 1 N AeroSync PB 10 power bank
- 1 N User Manual Scan Card
- 1 N Charging Cable
- 1 N Rating Card

Product Overview



Operating Instructions

How to Charge Devices with the Powerbank

Wired Charging

- Connect your digital device to a USB-A or USB-C port of the powerbank with a quality charge cable. This model doesn't need to press the button to start the charging, just plug in and charging will start.

Note: We recommend you to use the original cable provider by mobile brands or Ambrane for a better charging experience.

- After connecting, LED indicators on the powerbank will turn ON automatically. The first four Indicators will display the battery capacity ratio and the fifth green LED indicator will turn ON while Quick Charge or Power Delivery mode is activated.

Wireless Charging

- AeroSync PB10 is compatible with Qi-enabled wireless charging devices.
- Place your Qi-enabled device on the wireless charging pad. Make sure the device is aligned at the top of the charging base. Then press the power button to start the wireless charging.
- Green LED indicator will blink 2-3 times indicating it is sensing the wireless charging.
- Once the charging starts, the Green indicator will glow continuously.

Note: For wireless charging, the distance between the charging Pad and the smartphone will be less than 4mm for a better and more stable charging experience.

How to Charge the Power Bank?

A quality charge cable with a USB-C connector on one end and a USB-A or USB-C on the other end can be used. Plug the USB-C connector of the cable into the powerbank's input port (Type-C) and the other connector into the matching port of a USB power adapter. The LED indicator will start to flash and then stay solid one by one as the charging progresses.

- **Few Important Tips to Charge the Powerbank**
- Use Type-C to Type-C cable for PD charging and USB-A to Type-C cable for QC charging.
- We recommend using the QC/PD 20W power adapter to get an enhanced charging speed.

Note: We recommend using a BIS-certified adapter to charge the powerbank.

- While connecting QC or PD input, the fifth green LED indicator will glow which reflects the powerbank is in fast charging mode and the corresponding battery capacity indicator will blink.
- When fully charged, all four white LED indicators will turn ON and the blinking will stop.
- After the powerbank is fully charged, unplug the USB cable from the Powerbank.

Note: We suggest not to exceed the time up to one hour after fully charged for better safety of the powerbank.

Product Specifications

Battery Capacity	: 10000mAh
Battery Type	: Lithium-Polymer
Input Port	: 1 N Type-C (QC/PD)
Output Ports	: 1 N Type-C (PD Compatible) 1 N USB-A (QC Compatible)
Input	: DC 5V=2.6A, 9V=2.1A, 10V=2A, 20W (max.)
Output (QC/PD)	: DC 5V=3A, 9V=2.5A, 12V=1.87A
Wattage	: 22.5W (Max)
Wireless Output	: 15W (Max)
Charging Time	: Up to 3 Hrs through PD Technology

Indication of Charging and Discharging

Charging the Powerbank:

Connect with a suitable charging source. The indicators show charging conditions as follows:

Power Level	LED-1	LED-2	LED-3	LED-4	LED-5 (Green, QC/ PD, Qi Mode)
0-25%	Blinking	OFF	OFF	OFF	ON
25-50%	ON	Blinking	OFF	OFF	ON
50-75%	ON	ON	Blinking	OFF	ON
75-100%	ON	ON	ON	Blinking	ON
Fully Charged	ON	ON	ON	ON	ON
Charging Error	Blinking	Blinking	Blinking	Blinking	Blinking

Charging Products from Powerbank:

Connect your device with the powerbank to charge. The indicator shows discharging conditions as follows:

Power Level	LED-1	LED-2	LED-3	LED-4	LED-5 (Green, QC/ PD, Qi Mode)
Fully Charged	ON	ON	ON	ON	ON
75-100%	ON	ON	ON	ON	ON
50-75%	ON	ON	ON	OFF	ON
25-50%	ON	ON	OFF	OFF	ON
25-10%	ON	OFF	OFF	OFF	ON
10-0%	Blinking	OFF	OFF	OFF	OFF
Charging Error	Blinking	Blinking	Blinking	Blinking	Blinking

Safety alerts and Guidelines

- Keep your Powerbank dry and away from moisture and corrosive materials.
- Do not clean your Powerbank with harsh chemicals, soaps or detergents. Just wipe it with a soft and dry cloth or use a microfiber cloth.
- To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Do not expose this unit to extremes of temperature.
- Immediately terminate use of the product if the item bulges, smells or leaks.
- Please recharge the Powerbank once a month if not in use to extend the lifetime of the battery.

- Please allow the Powerbank to deplete significantly before recharging in order to preserve the lifetime of the battery.
- Check the voltage of the USB devices and power adaptors carefully before using them.
- Please ensure that there are no metal or magnetic things (cases, rings, coins, keys, etc.) around before using the wireless charging feature.
- Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the rubber finish could cause marks or staining where the product resides.
- Keep your device out of reach of small children to prevent danger.
- Lithium batteries, like all rechargeable batteries are recyclable and should not be recycled or disposed of in the normal household waste. Contact your local government for disposal or recycling practices in your area. They should be incinerated since they might explode.
- Keep away from fire, water and excess temperature ($> 45^{\circ}\text{C}$) and too low temperature ($< -20^{\circ}\text{C}$)
- Do not dismantle, crush, puncture and short circuit the powerbank, or expose it to liquids, fire or an environment where the temperature is above 55°C .

Precautions

- Some USB cables that are not compatible with the powerbank or can't be used should be avoided, instead, choose or purchase the charging cable of the same mobile brand to get adequate speed.
- When the powerbank won't charge digital products, please check whether the charging cable and connectors are connected properly or change the cable. After digital devices are fully charged, please unplug the charging cable timely to avoid power loss.
- Because of the high charge and discharge current, please choose good quality charging cable and connectors.

Please make sure the powerbank is fully charged when using it for the first time. Make sure that the product is fully charged at least once in two or three months.

Prolonged use will increase the temperature of the powerbank which is a normal phenomenon.

During charging of the powerbank, please unplug the cable within 30 mins when the powerbank is fully charged else overcharging will harm the battery.

While using output through a single port, the powerbank delivers maximum power but if dual or more ports are used at the same time, then the powerbank will divide power into two or three. For Eg: Powerbank Maximum Current delivers 3.0A.

In single port usage, the Powerbank will operate in only one parameter whether QC or PD and will provide the output ratio mentioned.

If all the ports are used in a single phase then the powerbank will work on basic parameters and the current will be divided into all the ports.

Warranty Card and Terms & Conditions

- NOTE: For valid warranty claim, all information on the warranty certificate has to be completed and presented along with the original invoice.
- All warranty information, product features and specifications are subject to change without prior notice.
- All matters are subject to Delhi Jurisdiction.

Customer's Name: _____

Contact Number: _____

Customer's Address: _____

Model No.: _____

Purchase Date: _____

Invoice Number: _____

Dealer's Stamp: _____

- Ambrane Aerosync PB 10 powerbank comes with 180 days warranty from the date of purchase.
- Warranty can not be claimed if the product is damaged by wrong operation or force majeure.
- Accessories supplied with Ambrane Aerosync PB 10 powerbank are not covered under the warranty.

CUSTOMER CARE:

Ambrane India Pvt. Ltd.

224, Second Floor, D-Mall, Netaji
Subhash Place, Delhi; India - 110034

Contact No.: +91 1145911111,

E-mail: care@ambraneindia.com

Web: www.ambraneindia.com

Join the Ambrane Ally!
[@ambraneindia](#)

