



**DISPLAY SO BIG,  
IT FEELS INFINITE!**

***Wise Eon Max***

**BLUETOOTH CALLING**



100+ Watch  
Faces



Voice  
Assistance



2.01"  
LucidDisplay™

**USER MANUAL**

## Welcome

---

Thank you for purchasing the Ambrane Wise Eon Max smartwatch. We recommend you to read the instructions manual carefully before using the product.

## Package Contents

---

- 1N Ambrane Wise Eon Max
- 1N User Manual Scan Card
- 1N USB Magnetic Charging Cable
- 1N FAQ Card
- 1N Rating Card

## Product Overview

---



## Turning the Watch ON

---

To turn the watch on, press the key on the right side of the watch for 4 to 5 seconds.

**NOTE:** The smart watch must be charged before initial use.

You can wake the screen by lifting your wrist. Enable the Quick View feature on the app to function.

## Charging the Watch

1. Turn the watch over, align and attach the charging pins to the magnet gold prongs.
2. You will see the charging icon on the watch screen after 5 seconds.
3. Complete charging may take up to 2 hours. The battery icon would change to full once the charging is complete.
4. Please clean the charging points before charging to avoid erosion of the gold prongs and other risks.

### Download and Install the App by the name of "Da Fit"

You can set up the Smartwatch through the "Da Fit" app for iOS or Android devices. Scan the QR code from your watch to get Da Fit in your app store.




SCAN THE QR CODE  
FOR APP

DO NOT PAIR THE WATCH DIRECTLY WITH BLUETOOTH IN YOUR PHONE'S SETTINGS.

## Pairing Instructions

1. Turn on Bluetooth on your smartphone.
2. After installing the Da Fit app on your smartphone, register and log into your account as per the instructions on the screen.
3. Ensure that the smartwatch and smartphone are kept near each other.
4. Continue following the onscreen instructions to connect or pair your smartwatch to your smartphone.

Open App > Device > Add a new device > Choose Wise Eon Max.

5. Select the Bluetooth name Wise Eon Max from the list. The watch will show a pairing notification, click on  to confirm pairing.

**Note:** The device should have at least android 6+ or iOS 10.0+ and above. The watch can only be paired with one smartphone at a time. To pair any other smartphone, please unbind the currently connected smartphone before pairing.

## Pairing Instructions for Bluetooth Calling

1. For most Android smartphones, after the watch is connected to the app correctly, there will be a "Pair" pop-up reminder, choose to pair. The connection would be successfully completed.
2. For all iOS mobile phones and a few Android smartphones, after the watch is connected to the app correctly, go to the 'Settings' page of your smartphone, search and select "Eon Max Phone" in your Bluetooth list, and then click to pair. The Bluetooth Call feature can be used after being successfully paired.

### Tips:

1. Please upgrade the app to the latest version to get a better experience.
2. For the first time connection with an iPhone, a "Pair" reminder will pop up. Click to pair, then incoming calls and instant messages will be pushed.
3. For the first time connection with Android, a "Permissions" reminder will pop up, please follow up on the guidance and allow permissions to ensure all functions working properly.
4. To connect successfully, please turn ON the smartphone's Bluetooth, GPS and network.
5. If the device cannot be searched or connected during use, please reset or turn OFF the watch to try again.

## Synchronize Data

In daily wear, the watch can detect and record all kinds of data. The user needs to connect the smartwatch with Bluetooth on the app and enable it to synchronize.

**Note:** To prevent data loss, please synchronize the watch at least once every 7 days.

## Watch Faces

Your Ambrane Wise Eon Max comes with 100+ watch faces for you to choose from. Once you pick your favourite watch face, your home screen will display the date, time, week, weather, steps you take, battery status and connection status. Long press the screen, swipe to choose and click to confirm.


**Custom Watch Faces:** Open the app> Go to Device> Click on Watch Faces. Now, choose your desired watch face by clicking on "More Watch Face." Now, click on the "Download" button to apply.

## Steps, Distance & Calorie Monitor

You can view daily records of steps, distance and calories on the app as well as on your smartwatch. The data will be cleared at the end of every day.

**NOTE:** All records will be available on the app if you keep it synchronized.

## Bluetooth Calling (Phone)



Quick dial any number, view recent calls and contacts by clicking on the Phone icon.

## Sleep Monitor



It automatically tracks your sleep. After wearing the watch properly, tap on the Sleep icon in the watch: Record the sleep status throughout the night.

**NOTE:** You need to wear the watch for the measurements.


## Heart Rate



Tap on the icon to measure your heart rate. Wear the watch on your wrist correctly and stay still.

**NOTE:** Measurements are for reference only and not for medical purposes.

## Exercise Modes



Go to Exercise to choose amongst different Exercise Modes. There are a total of 100+ Exercise Modes on the Eon Max watch.

During Sports

To Pause: Short press the right key

To End: Short press the right key

## Blood Pressure



Click on the BP icon to check your blood pressure.

**NOTE:** Measurements are for reference purposes only.

## SpO2



Wear the watch on your wrist, then click on the icon to start measuring. You can also view the data on the app.

**NOTE:** Measurements are for reference only and not for medical purposes as this is not a medical-grade equipment.

## Weather



It shows you the weather forecast when the watch is connected with the app.


## Camera Control Mode (Shutter)



Click on the remote camera icon on your watch Flash to click a photo from your phone.

**NOTE:** For both android & IOS, you need to turn on the camera from the app and trigger from the watch.

## Music Control Mode (Player)



Tap on this icon to launch music control mode.


**NOTE:** Ensure the music app is running on your phone for this feature to work properly. This feature might not work for some of the Music Apps with different control protocols.

## Breath Training Mode (Breathe)




Tap on the icon, now tap to start breath mode and then focus on your breath.

## Stopwatch




Tap on this icon to use the stopwatch.

## Alarm



Set the alarm in the app and sync to the watch. You can set up a maximum of 3 alarms at a time.

## Menu View



Eon Max comes with 2 different menu views (Grid & List View). You can choose the menu style according to your choice.




## Brightness



Click on the brightness icon to adjust brightness levels. To maximize battery life, keep your watch brightness at 0 or 1.

## Do Not Disturb Mode



After turning ON the DND mode, the watch will no longer receive message reminders.

## Reset



Go to Settings and then tap on the Reset icon to reset your watch.

**NOTE:** All data will be lost.

## Turning The Watch Off



Press and hold the side button for 3 seconds, Tap on Power Off.

## Restart




Go to settings and then tap on the Reset icon to reset your watch.

## Swipe Down to access the Shortcut Menu



You can access Brightness, Camera, Flashlight, Settings and more from the shortcut menu.

## Call and Text Notifications




Turn this feature ON from your app to receive instant notifications and call alerts. 5 latest messages will be shown.

## Flashlight



Swipe Down and Tap on the icon to turn your watch screen into a flashlight when in need.

## Game



There are 3 fun inbuilt games in the watch that can get those boring moments away.

## Cleaning and Maintenance

1. Keep the product clean.
2. Keep the product dry.
3. Do not wear it too tight.
4. Do not use household cleaners to clean the watch. Use a soap-free detergent if you need to clean it.

## Safety and Product Information Notes

### Battery Warning:

Do not disassemble, pierce or damage the battery. Do not disassemble the built-in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

### Health Warning:

The watch's optical heart rate sensor glows green and ashes. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician to ask if you can wear this product. The device tracks your daily activities through sensors. These data are intended to tell you about your daily activities, such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

The device, accessories, heart rate sensors and other relevant data are designed for entertainment & fitness, not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms.

The heart rate data is for reference only. We are not responsible for any consequences caused by any data deviation.

## Matters Needing Attention

- Watch data needs to be kept once every 7 days to avoid data loss.
- The watch has no waterproof effect on seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquids
- The damage or defects caused by misuse or improper use are not covered by the warranty.
- Avoid wearing the watch too tight in daily use. Please keep the parts of the watch touching the skin dry.
- When your heart rate is measured, keep your arm still during the test.

## Caution

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE  
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycling valuable raw materials and the treatment of toxic substances.

## Warranty Terms & Conditions

---

- All warranty information, product features, and specifications are subject to change without prior notice.
- All matters are subject to Delhi Jurisdiction.
- This smartwatch comes with 365 days warranty from the date of purchase.
- Warranty can not be claimed if the product is damaged by wrong operation or force majeure.
- The accessories (magnetic pin charging cable) which come along with the smartwatch come under a warranty of 90 days.
- The wear-and-tear accessories such as the straps are not covered under warranty.

### **CUSTOMER CARE:**

Ambrane India Pvt. Ltd.  
224, Second Floor, D-Mall, Netaji  
Subhash Place, Delhi; India - 110034  
Contact No.: +91 1145911111,  
E-mail: [care@ambraneindia.com](mailto:care@ambraneindia.com)  
Web: [www.ambraneindia.com](http://www.ambraneindia.com)

Join the Ambrane Ally!

[@ambraneindia](#)

