JUMPSLIDE

Assembly Manual









Share your fun on instagram #Jumpflex



Australia



New Zealand



USA



Canada



UK

(1800 586 735

(0800 586 735

(1866 305 7238

📞 1866 305 7238

(0330 010 4301




Warning: Read all assembly, installation, care, maintenance and use instructions in the manual prior to assembling and using this Jumpflex accessory.


These products are for personal use only by 1 person aged 6 years and older, for outdoor use.

Warning: For domestic use only. Adult assembly required.

Risk Warning: The use of this product involves a significant risk of participants suffering personal injury including the possibility of serious injuries, permanent disability or death. All participants who engage in activities with the product do so at their own risk.

Parts List





	Part Type	Quantiy
1	JS-Slide	1
2	JS-Plate	1
3	JS-Handle	2
4	JS-Ubolt	2
5	JS-Nuts and Bolts	4

Jumpflex™ Trampolines

JUMPSLIDE



Select JS-Handle and insert the long end first into the holes on the top of the green slide.

Repeat this on the other side making sure that both are sitting correctly and are aligned with the bolt holes on the side of the Slide. This creates the handles of the slide.




02

Turn the Slide on its side and loosely attach (finger tight) the bolt through the hole in the slide and handle in the position as shown on both handles. Don't insert a bolt on the other end of the handle, this will come in the next step.



03

Now insert JS-Plate as shown into the exposed bottom of JS-Handle. Take your time to insert JS-Plate evenly.



JUMPSLIDE



To help align the bolt holes on the handle and slide, we recommend using the provided screwdriver. Insert the screw drive and wiggle it through all holes to help align the holes.

Using the remain two bolts fasten the bottom of the handle to the slide. Now Securely tighten all 4 bolts.



05

Select the location you would like the Slide to be positioned on your Jumpflex Trampoline. This can be anywhere, we often move the Ladder over and position the slide next to the Ladder in the entrance to the Trampoline. Lift up the Spring Pad so that is it out of the way of where you are attaching the Slide.



03

Using the provided U-bolt place this over the Trampoline frame and fasten down through the top of JS-Plate as shown. Attach both U-bolts and secure firmly. Pull the Spring Pad back down over the springs and re-attach to the frame with the Padding straps.



Congratulations!

You have finished the assembly of your Jumpflex Jumpslide



Share your fun with us on instagram #Jumpflex



Play for Life

Jumpflex™ Trampolines 6

Jumpflex™ Trampolines

7

Play for Life