

SMARTSHADE

Assembly Manual

JumpFlex™
play for life

v2.0

SMARTSHADE

REMOVE DURING WIND AND RAIN
DO NOT LEAVE ATTACHED INDEFINITELY.

01

Locate the webbing clip and buckle.

02

Wrap the clip end of the webbing over and around the top of the Safety Net pole, as shown.

03

Connect the clip and buckle, and tighten into place.
Repeat this on each Safety Net pole to complete the attachment of your Jumpflex SmartShade.

Warning: Read all assembly, installation, care, maintenance and use instructions in the manual prior to assembling and using this Jumpflex accessory.

Warning:
For domestic use only.
Not to be left attached indefinitely.
Designed for intermittent use only while on your trampoline.
Not suitable for use during wet or windy weather.
Keep cover clear of leaves and debris.