

Item type
Coffee Table
Item name
Soren

Attention!
Place the item on a padded area to prevent damage to the item.

Care instructions:
Dust regularly and clean with a soft dry cloth. Remove spills immediately to avoid staining and always use a coaster.

Eichholtz B.V.
Delfweg 52
2211 VN Noordwijkerhout
The Netherlands

🏠 www.eichholtz.com
✉ service@eichholtz.com
☎ +31 (0)252 515 850

