



BACKYARD *expressions*

PATIO • HOME • GARDEN

ASSEMBLY INSTRUCTIONS (Maximum Weight: 300LBS.)

Item NO: 910113

Item NO: 909727

UPC: 68112 910113 9

UPC: 68112 909727 2

This is a wood product that will weather if kept outside. Also, it is suggested that in late fall you bring the bench inside and store in a cool, dry place. If left outside over the winter the wooden bench may age prematurely.

Parts List:

A: 2PCS



D: 4PCS



E: 2PCS



F: 4PCS




B: 1PC




C: 1PC



Step 1:



Step 2:





BACKYARD *expressions*

PATIO • HOME • GARDEN



- Hand tighten all bolts to make sure that the bolts are not overtightened. Periodically, every couple months, check the bolts to make sure they are tightly secured to the bench.
- Make sure you assemble the bench on level ground.
- If you turn the bench over to assemble please place the bench on a soft surface so you do not scratch the seat of the bench.
- Make sure to hand tighten all screws and bolts. Once all screws and bolts are in place you can then go back and re-tighten all hardware. Be careful not to over-tighten hardware.
- If you use this item outside please know that it is a wooden item and it will weather in time from sun, rain and snow. It is suggested to bring the item inside if weather is not suitable for wood.
- The manufacturer is not responsible for failure of this product due to normal weathering. Any claims submitted about the structure of this product due to weathering will be reviewed at the discretion of the manufacturer.



BACKYARD expressions

PATIO • HOME • GARDEN



Please help us give you the best possible service by emailing your parts & service needs to: CustomerService@DDIcorp.com

Emails are responded to daily and are the most accurate way to communicate item/parts needs. Purchase receipt is necessary for any warranty claim or assistance.

In addition to your purchase receipt please include the following information in your email:

Item Name	31.5" Or 43.3" Wooden American Flag Bench
Item UPC Code	68112 910113 9 2 Or 68112 909727 2
Specific Issue	
Part Needed—Please Identify from Assembly Instructions	
Your Shipping Address	

Parts and parts listings for many of our products can be found at:
<https://backyard-expressions.com/collections/replacement-parts>

PRODUCT WARRANTY SHALL NOT APPLY TO ANY PRODUCT OR ANY PART THEREOF, WHICH HAS BEEN SUBJECT TO ACCIDENT, NEGLIGENCE, WEATHER RELATED DAMAGE, ALTERATION, ABUSE, OR MISUSE OR TO PRODUCT SOLD AS-IS, END OF SEASON, OPEN BOX OR OTHER SUBSTANTIALLY DISCOUNTED PRODUCT.

DDI MAKES NO WARRANTY WHATSOEVER IN RESPECT TO ACCESSORIES OR PARTS NOT SUPPLIED BY US.

DDI IS NOT RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHICH MAY ARISE OUT OF THE PURCHASE OR USE OF ANY DDI PRODUCT.

PRODUCT LIABILITY FOR ANY BREACH OF THIS WARRANTY SHALL BE AT THE DISCRETION OF DDI AND LIMITED TO REPAIR OR REPLACEMENT OF THE DEFECTIVE PRODUCT.

WARRANTY CLAIMS RECEIVED 90 DAYS AFTER PURCHASE DATE (RECEIPT REQUIRED) MAY BE SUBJECT TO ADDITIONAL COSTS AND ARE ASSESSED BY THE WARRANTY CLAIM DEPARTMENT.